

SONY

Hi-Fi Products
Service Bulletin

Sony Service Company - Technical Services
A Division of Sony Corporation of America
Sony Drive, Park Ridge, New Jersey 07656

Model: Various Remote Commander **No.** 21

Subject: Part Number Of Battery Lid For Remote Commander **Date:** May 23, 1988

Symptom:
(**)

The part number of the battery lid for the remote commander is not listed in the service manuals of the models listed below.

Solution: Please add this part number to your service manual.

Ref No.	Description	Part Number
None	Battery Lid	3-704-112-01

List of models and remote commanders that use this battery lid.

Model	Remote Commander	P/N For Remote Commander
CDP-310	RM-D50	1-463-784-11
CDP-31	RM-D50	1-463-784-11
CDP-37	RM-D50	1-463-784-11
CDP-C5F	RM-D5	1-463-796-11
CDP-C5M	RM-D5	1-463-796-11
CDP-C57	RM-D5	1-463-796-11
CDP-50	RM-D30	1-463-719-11
STR-AV31	RM-S30	1-463-830-11
STR-AV340	RM-S340	1-463-730-11
D-2001	RM-D2001	1-463-844-11
RM-DM1K	RM-DM1	1-463-789-11
TC-WR950	RM-950	1-463-797-11
XO-D4	RM-D5	1-463-796-11
TA-SR310	RM-310	1-463-733-11
XTV-8	RM-X8	1-463-780-11

Miscellaneous

CSA-13