

**SONY**

Hi-Fi Products  
**Service Bulletin**

Sony Service Company - Technical Services  
 A Division of Sony Corporation of America  
 Sony Drive, Park Ridge, New Jersey 07656

**Model:** TC-W285/W380

**No. 71**

**Subject:** Missing Part Numbers


**Date:** May 24, 1989

**Symptom:**  
 (\*\*)

**Solution:** Please add the following part numbers to your service manual:

(5) DECK B (2)

Bulletin Reference	Description	Part Number
A	Spring	4-894-978-01
B	Spring "B" Deck	4-894-979-01
C	Spring	3-390-889-01
D	"S" Arm	4-894-982-01
E	Function Lever	4-894-984-01
F	"C" Spring	4-894-983-01
G	Square Belt	3-390-816-01
H	Power Arm Assembly	4-894-997-01
I	Spring	4-894-999-01
J	Play Lever	3-390-810-01
K	REC Stop Lever "B" Deck	3-390-811-01
L	Spring "A" Deck	3-390-827-01
M	"SE" Lever	4-894-987-01
N	Pause Lever	4-894-986-01
O	Pause Arm	4-894-985-01



**CSA-13** Tape Deck

Reference: Technical Department

PRINTED IN U.S.A.  
 CSA-13589-1