

SONY

Hi-Fi Products
Service Bulletin

Sony Service Company Technical Services
A Division of Sony Corporation of America
Sony Drive, Park Ridge, New Jersey 07656

Model: D-180K

No. 143

Subject: Open Button Replacement


Date: November 19, 1990

Symptom:
(14)

Open button comes off unit.

Solution: If this symptom occurs, replace the open button and spring with the improved parts.

Ref. No.	Description	Part Number
8	Open Button	4-924-130-01
7	Spring	4-942-162-01



CSA-13 Discman

Reference: GA90012

PRINTED IN U.S.A.
CSA-131190-2