

SONY

Hi-Fi Products
Service Bulletin

Sony Service Company Technical Services
A Division of Sony Corporation of America
Sony Drive, Park Ridge, New Jersey 07656

Model: MHC-5500

No. 167

Subject: Factory Presets

Date: February 28, 1991

Symptom:
(**)

The customer has changed the factory presets in his unit and wishes to return it to the original settings. There is no default or reset mode to obtain factory presets.

Solution: The factory presets are listed below. The unit will have to be manually returned to factory presets.

Preset	On/Off			Surround		Frequency 1		Frequency 2		Frequency 3		DDS
	DDS	EQ	Surround	Time	Level	Freq. (Hz)	Level	Freq. (Hz)	Level	Freq. (Hz)	Level	
L-HALL	X	O	O	2.4	-8	100	4	562	2	7.5K	2	---
S-HALL	X	X	O	1.8	-10	75	0	750	0	7.5K	0	---
JAZZ CLUB	X	O	O	1.2	-10	100	-2	3.16K	2	7.5K	2	---
STADIUM	O	O	O	2.4	-4	75	4	237	2	3.16K	2	CP2
DISCO	O	O	O	30	-10	23.7	-12	100	12	4.22K	6	CP2
MOVIE	O	O	O	25	-6	100	4	750	2	17.8	-2	CP3
SYMPHONY	O	X	O	60	-10	75	0	750	0	7.5K	0	CP2
SIMULATED	O	O	O	25	-16	100	4	750	2	17.8K	-2	CP4
NIGHT	O	O	O	2.4	-12	100	4	562	2	17.8K	-2	CP2
BGM	O	O	O	2.4	-8	23.7	-8	750	2	17.8K	-2	CP3
WM	O	O	O	1.6	-20	178	8	1.0K	4	17.8K	-2	CP2
CAR	O	O	O	1.6	-8	133	-2	5.62K	2	17.8k	4	CP4

Note: X = Off
O = On

Reference: Fax A910014

PRINTED IN U.S.A.
CSA-13191-9

Receiver

CSA-13