

SONY

Hi-Fi Products
Service Bulletin

Sony Service Company Technical Services
A Division of Sony Corporation of America
Sony Drive Park Ridge, New Jersey 07656

Model: D-2, D-11


No. 210

Subject: Prevention of Flex Cable Damage

Date: September 20, 1991

Symptom:
(**) Cracking of the printed wiring portion of the optical assembly flex cable can be prevented by performing the following procedure.

Solution: Bend the flex cable along the dotted line as shown:



This procedure should be performed on every D-2 and D-11 that is being repaired, regardless of the reason.

CSA-13 Portable Disc Player