

**SONY**

Hi-Fi Products  
**Service Bulletin**

Sony Service Company - Technical Services  
A Division of Sony Corporation of America  
Sony Drive, Park Ridge, New Jersey 07656

**Model:** TC-RX420

**No.** 220

**Subject:** Part Number for PLAY Indicator Led Lenses Not Listed In Service Manual.


**Date:** October 31, 1991

**Symptom:**  
(\*\*)

The play indicator led lenses located above the play buttons on the front panel are not referenced in the Service Manual.

**Solution:** The part number for the PLAY indicator led lens is as follows:

DESCRIPTION	PART NUMBER
LENS, PLAY INDICATOR	3-340-195-02



LENS, PLAY INDICATOR

CSA-13 Tape Deck

Reference: FPR M2175

PRINTED IN U.S.A.  
CSA-131091-3