

SONY

Hi-Fi Products
Service Bulletin

Sony Service Company Technical Services
A Division of Sony Corporation of America
Sony Drive Park Ridge, New Jersey 07656

Model: HST-D105

No. 221

Subject: Unit does not maintain station presets when power is turned off. **Date:** November 8, 1991

Symptom: (21) The owners manual for this model indicates that the unit will accept 30 station presets. While you can set 30 preset stations, all presets are lost when power is turned off. However, if you only set 28 presets, the presets remain when power is turned off.

Solution: The display control micro IC601 contains a software bug. Replace micro IC601 in accordance with the chart below:

REFERENCE	INCORRECT		CORRECT	
	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.
IC601	μPD75212ACW-276	8-759-154-08	μPD75212ACW-299	8-759-154-96
	μPD75212ACW-267	8-759-153-72		
	μPD75217ACW-062	—		

CSA-13 Compact System