

**SONY**

Hi-Fi Products  
Service Bulletin

Sony Service Company - Technical Services  
A Division of Sony Corporation of America  
Sony Drive, Park Ridge, New Jersey 07656

**Model:** D-101/202

**No. 283**

**Subject:** Skipping Or No Play When Used In High Temperature Environment.

**Date:** August 3, 1992

**Symptom:** (57) The unit skips or will not play when used in a high temperature environment.

**Solution:** Change the following components on the Main Board:

REF.	FORMER		NEW	
	DESCRIPTION	PART NUMBER	DESCRIPTION	PART NUMBER
C-539	CAPACITOR, CERAMIC CHIP 470pF	1-163-133-00	RESISTOR, METAL CHIP 750K	1-218-118-00
R-533	RESISTOR, CHIP 2.7K	1-216-059-00	RESISTOR, CHIP 0Ω	1-216-225-00
C-530	CAPACITOR, CERAMIC CHIP 0.015μF	1-163-023-00	CAPACITOR, CERAMIC CHIP 1μF 16V	1-164-246-11

CSA-13 CD Player

