

SONY.

Hi-Fi Products
Service Bulletin

Sony Service Company - Technical Services
A Division of Sony Corporation of America
Sony Drive, Park Ridge, New Jersey 07656

Model: HCD-D115/D117/H5/H50/H150,
HST-111/D105

No. 299

Subject: Pinch Roller Shaft Not Supplied With Pinch Roller

Date: October 30, 1992


Symptom:-
(**)

The pinch roller shaft is not included with the pinch roller when ordered from the National Parts Center using part number 3-578-143-11. The exploded view drawing in the Service Manual indicates that the shaft comes with the pinch roller.

Solution:

When the shaft for the pinch roller is needed for replacement, order the lever (pinch lever) Assy as shown in the chart below:

DESCRIPTION	PART NUMBER
Lever (Pinch Lever) Assy	X-3358-204-1



CSA-13 Compact System