

**SONY**

Hi-Fi Products  
Service Bulletin

Sony Service Company - Technical Services  
A Division of Sony Corporation of America  
Sony Drive, Park Ridge, New Jersey 07656

**Model:** STR-D790 / D990 / D1090, RM-U221

**No. 326**

**Subject:** All functions do not operate from the remote commander

**Date:** March 19, 1993

**Symptom:**  
(25)

The remote commander (RM-U221) does not control all functions as indicated by the button controls on the remote. This is most often the case with the Tuner preset controls on the remote commander.

**Solution:**

Remove the batteries from the RM-U221 remote and depress and hold the power button on the remote for 2 seconds. Re-install the batteries and all controls are restored to the remote.

CSA-13 Amplifier / Integrated Amp

Reference: FPR-00587



PRINTED IN U.S.A.  
CSA-13393-1