

SONY.

**Hi-Fi Products
Service Bulletin**

Sony Service Company - Technical Services
A Division of Sony Corporation of America
Sony Drive, Park Ridge, New Jersey 07656

Model: DXA-H2750/H3750

No. 331

Subject: Extension Cable Jigs

Date: March 31, 1993

Symptom:

(**) There are now (6) types of extension cables available to aid in the repair of the models listed above.

Solution:

The part numbers for the extension cable jigs are as shown in the chart below. Connect the extension cable jigs to the unit as shown in the drawing below.

| NO. PINS | DESCRIPTION | PART NUMBER | APPLICABLE MODEL | |
|----------|--|--------------|------------------|-----------|
| | | | DXA-H2750 | DXA-H3750 |
| 5 | CONTROL BOARD CN503 TO POWER BOARD CN801 | J-2501-041-A | YES | NO |
| 4 | MAIN BOARD CN107 TO POWER BOARD CN802 | J-2501-042-A | YES | YES |
| 7 | POWER BOARD CN801 TO HP BOARD CN3 | J-2501-043-A | NO | YES |
| 7 | CONTROL BOARD CN501 TO MAIN BOARD CN109 | J-2501-049-A | YES | YES |
| 13 | TC MAIN BOARD CN609 TO MAIN BOARD CN104 | J-2501-050-A | YES | YES |
| 15 | CONTROL BOARD CN502 TO MAIN BOARD CN108 | J-2501-051-A | YES | YES |

