

Hi-Fi Products Service Bulletin

CSA-13

Sony Service Company - Technical Services
A Division of Sony Electronics Inc.
Sony Drive, Park Ridge, New Jersey 07656

Model: HCD-H550M

No. 409

Subject: Extension Jigs Available


Date: September 7, 1994

Symptom:

(**) Extension jigs are needed to connect the main board to the switch board and display board while servicing this unit.

Solution: Use the parts listed to connect the main board to the switch board and display board.

Description	Part Number	No. of Pins	Points Connected
Display bd to main bd cable	J-2501-073-A	20P	CN101-CN501
Switch bd to main bd cable	J-2501-070-A	22p	CN201-CN751



Filename: HFP0409.SB
Directory: J:\SBDOC\SEP94
Template: C:\WINWORD\S_BULL.DOT
Title: Extension cables
Subject:
Author: Hoyt Wing Lee
Keywords:
Comments:
Creation Date: 09/07/94 2:10 PM
Revision Number: 2
Last Saved On: 09/07/94 2:10 PM
Last Saved By: Hoyt Wing Lee
Total Editing Time: 0 Minutes
Last Printed On: 04/01/96 10:54 AM
As of Last Complete Printing
Number of Pages: 2
Number of Words: 135 (approx.)
Number of Characters: 775 (approx.)