

# Hi-Fi Products Service Bulletin

**CSA-13**

Sony Service Company - Technical Services  
A Division of Sony Electronics Inc.  
Sony Drive, Park Ridge, New Jersey 07656

**Model:** STR-D665

**No.** 454

**Subject:** Display Disappears after awhile

**Date:** November 10, 1995

**Symptom:**

(13)

The display will disappear shortly after the unit is powered on.

**Solution:**

If the Customer complains of the display going dark, replace R808. This thermistor is located on the main board. Replace the parts listed below.

REF	FORMER		NEW	
	DESCRIPTION	PART NUMBER	DESCRIPTION	PART NUMBER
R808	THERMISTOR, 100 OHM	N/A	CARBON RESISTOR, 100 OHM	1-249-405-11

**Note:** R808 is shown as a resistor in the schematic diagram when in fact, it is a thermistor.



Filename: HFP0454.SB  
Directory: J:\SBDOC\NOV95  
Template: C:\WINWORD\TEMPLATE\S\_BULL.DOT  
Title:  
Subject:  
Author: Hoyt Wing Lee  
Keywords:  
Comments:  
Creation Date: 11/10/95 10:09 AM  
Revision Number: 2  
Last Saved On: 11/10/95 10:09 AM  
Last Saved By: Hoyt Wing Lee  
Total Editing Time: 1 Minute  
Last Printed On: 04/01/96 10:18 AM  
As of Last Complete Printing  
Number of Pages: 1  
Number of Words: 144 (approx.)  
Number of Characters: 822 (approx.)