

del: D-840K, D-242CK, D245**No.** 516R1**Subject:** Skipping when unit is in ESP Mode**Date:** April 14, 1997**Symptom:****(157)**

Unit skips in ESP mode system (even when stationary),but does not skip when ESP is off. RF level (eye pattern) is also good

Solution:

Check the lot number of IC 502. If it is less than 528, replace the IC. Make sure the lot number is 528 or later .Check the lot number of the DSP/SSP IC . If it is less than 528, replace the IC. Make sure the lot number is 528 or later.

UNIT	REF #
D-242CK, D-245	IC601
D-840	IC502

