

Model: TC-WE805S

No. 528

Subject: Part Number Correction

Date: May 23, 1997

Symptom:

(**)

The exploded view shown on page 47 of the Service Manual outlining the Cassette Holder (L) Assy and the Cassette Holder (R) Assy are reversed.

Solution:

Refer to table shown below for the correct part number/reference number.

REF	DESCRIPTION	PART NUMBER
70	HOLDER, (L) ASSY, CASSETTE	X-4945-947-1
83	HOLDER, (R) ASSY, CASSETTE	X-4945-946-1

