

MDX-C5960R/C5970/C5970R

SONY

SERVICE MANUAL

German Model

MDX-C5960R

US Model

Canadian Model

E Model

MDX-C5970

AEP Model

UK Model

MDX-C5970R

CORRECTION-1

Correct your service manual as shown below.

| Page | INCORRECT | | | | CORRECT | | | |
|------|-----------|--------------|--|--------|----------|--------------|---|--------|
| | Ref. No. | Part No. | Description | Remark | Ref. No. | Part No. | Description | Remark |
| 72 | 16 | 1-776-527-71 | CORD (WITH CONNECTOR) (ISO) (POWER) (C5960R/C5970R) | | 16 | 1-776-527-71 | CORD (WITH CONNECTOR) (ISO) (POWER) (C5970R) | |
| | | | | | 16 | 1-776-527-91 | CORD (WITH CONNECTOR) (ISO) (POWER) (C5960R) | |
| 85 | 16 | 1-776-527-71 | CORD (WITH CONNECTOR) (ISO) (POWER) (C5960R/C5970R) | | 16 | 1-776-527-71 | CORD (WITH CONNECTOR) (ISO) (POWER) (C5970R) | |
| | | | | | 16 | 1-776-527-91 | CORD (WITH CONNECTOR) (ISO) (POWER) (C5960R) | |
| 86 | 511 | 1-776-527-71 | CORD (WITH CONNECTOR) (ISO) (POWER) (C5960R/C5970R) | | 511 | 1-776-527-71 | CORD (WITH CONNECTOR) (ISO) (POWER) (C5970R) | |
| | | | | | 511 | 1-776-527-91 | CORD (WITH CONNECTOR) (ISO) (POWER) (C5960R) | |

(ECN-CS805529)