

# CPD-200ES/200EST

## SERVICE MANUAL

*CPD-200ES*  
**US Model**  
**Canadian Model**  
*Chassis No.SCC-L16B-A*

## X2F CHASSIS

*CPD-200EST*  
**AEP Model**  
**UK Model**  
*Chassis No.SCC-L16A-A*

## CORRECTION-2





**Subject: Part number identification**

Correct the service manual as shown below.  
File this correction with the service manual.

 : Corrected item

**Section 6 Exploded Views (Page 29)**

**Section 7 Parts List - Miscellaneous (Page 40)**

Incorrect		Correct	
Part no.	Description	Part no.	Description
8-734-727-05 	CRT 17FRFM (M41LKN70X) (CPD-200ES)	8-738-731-05 	CRT 17FRSM (M41LKN70X) (CPD-200ES)
8-734-735-05 	CRT 17FRFM (M41LKN70X) (CPD-200EST)	8-738-734-05 	CRT 17FRFM (M41LKN70X) (CPD-200EST)

**TRINITRON® COLOR COMPUTER DISPLAY**



# SONY®