

SONY®

Service Bulletin

NO:HIFI2-01-010

SUBJECT: Unit May Shut Off With A Slight Shock

DATE: May 2001


MODEL (S): MZ-R55

Symptom: Unit may shut off with a slight shock when using Rechargeable Battery.

Solution:

1. Replace BATTERY CASE ASSY with a new one.
2. Add REC SWITCH SHEET to the Battery Case Assy as Figure.

Description	Part Number
SHEET, REC SWITCH	3-303-838-03



GA00030

Sony of Canada Ltd.

115 Gordon Baker Road, Toronto, Ontario M2H-3R6
NATIONAL LAB - CONSUMER SERVICE