

Repair tips

SUBJECT: Spindle motor buzzes and will not spin.

DATE: 04/25/02

MODEL (S): MZ-R37

Symptom: Spindle motor buzzes and will not spin.

Solution: Replace C707 33uf @6.3v first. This capacitor stabilizes the VM voltage to the spindle IC.

Submitted By: PHD Electronics Ltd.

Sony of Canada Ltd.

115 Gordon Baker Road, Toronto, Ontario M2H-3R6
NATIONAL LAB - AVIT