

**SONY.**

## Computer Monitors Service Bulletin

**CSI-111**

Sony Service Company - Technical Services  
A Division of Sony Electronics Inc.  
Sony Drive, Park Ridge, New Jersey 07656

**Model:** GDM17SE1

**No.** 60

**Subject:** Aging Mode

**Date:** June 24, 1994


**Symptom:**

(\*\*\*) How do you put this unit into Aging Mode ?

**Solution:**

Before Performing White Balance, you must place the unit into aging for 30 minutes. To Place this unit into Aging you must do the following:

1. Remove the R, G, B, H, and V signal connections from the unit.
2. Power ON the unit and wait for it to go into POWER SAVE (Power Save LED Comes ON).
3. Press and Hold the CTRL and POWER Buttons for 2 seconds then release. The Green Power LED will flash.



4. To exit the Aging Mode, Power OFF the unit.

