
Model: CPD-15SX1, CPD-100SX, CPD-200SX, CPD-15SF1, CPD-17SF1, GDM-17SE1, GDM-20SE1**No. 215****Subject:** Procedure for Built-In Raster Aging**Date:** August 24, 1998**Symptom:****(1181)**

The unit has come in for service. Raster Aging is necessary for testing symptoms and for warming the unit prior to adjusting set up. The Built-In Raster Aging mode should be used for this purpose. Special procedures are required to enable the Built-In Raster Aging functions.

Solution:

Please refer to the following procedures to put the unit into the Built-In Raster Aging modes. Use the procedure listed for the particular model. The times listed are approximate.

BUILT-IN RASTER AGING**CPD-15SX1, CPD-100SX:**

1. Connect AC cable and turn On Power Button.
2. Remove Video Cable. Wait for Power Save.
3. Remove AC Cable.
4. Reconnect AC Cable.

CPD-200SX:

1. Connect AC cable.
2. Remove Video Cable.
3. Press the Power Button in with " ← "&" → " buttons and hold for 3 seconds.

CPD-15SF1, CPD-17SF1:

1. Connect AC cable.
2. Remove Video Cable.
3. Turn On Power Button and hold The Power Button In For 2 Seconds

GDM-17SE1, GDM-20SE1:

1. Connect AC cable.
2. Remove Video Cable.
3. Press the Power Button in with " CNTL " button and hold for 3 seconds.

The set up procedure is completed.