


# AC-V25A

## SERVICE MANUAL

*US Model  
Canadian Model  
AEP Model  
UK Model  
E Model  
Australian Model*



AEP Model

This set does not support the repair of individual faulty parts.  
In case of failure, the main assembly must be replaced.  
The part code of main assembly is as listed below.

Part No.


A-7003-311-A (US model)  
A-7003-312-A (Canadian model)  
A-7003-313-A (AEP model)  
A-7003-314-A (Australian model)  
A-7003-315-A (UK model)  
A-7003-316-A (E model)

**AC POWER ADAPTER**  
**SONY**

# AC-V25B

## SERVICE MANUAL

*AEP Model  
UK Model  
E Model  
Australian Model*






This set does not support the repair of individual faulty parts.  
In case of failure, the main assembly must be replaced.  
The part code of main assembly is as listed below.

### Part No.

AC-V25B	A-6776-226-A (Tourist model)
AC-V25B	A-6776-237-A (AEP model)
AC-V25B	A-6776-238-A (UK model)
AC-V25B	A-6776-239-A (E model) - II -
AC-V25B	A-6776-240-A (Australian model)
NA-L1	A-6776-301-A (GRUNDIG AG model)
PC90A	A-6776-302-A (BLAUPUNKT WERKE model)

**AC POWER ADAPTER**  
**SONY**



RV301  
OUTPUT  
VOLTAGE

