


COMPONENTS INSIDE THE RESONANCE CELL CAVITY ARE SHOWN FOR REFERENCE ONLY AND DO NOT RESIDE ON ANY PRINTED CIRCUIT BOARD



REFERENCE DESIGNATORS:  
 600's ARE PART OF CELL HEATER  
 700's ARE INSIDE RESONANCE CELL  
 800's ARE PART OF LAMP HEATER  
 900's ARE PART OF DISCHARGE CIRCUIT  
 S=SOURCE OF SIGNAL ON THIS PCB  
 D=DESTINATION OF SIGNAL IS THIS PCB  
 P=PASS THROUGH OF SIGNAL ON THIS PCB