


Up-date of CD-Player A727 when using the PARALELL CONTROLLER 1.630.900.00

Before putting in operation please pay attention to the following flow chart:




Instructions for Hardware Modification on SERVO board 1.769.410.20

1. Remove the SERVO-BOARD of the A727 carefully. Therefore, disconnect the following cable connections:

- SERVO-BOARD ———▶ DECODER-BOARD
- SERVO-BOARD ———▶ CD-DRIVE
- SERVO-BOARD ———▶ DRAWER-MOTOR
- SERVO-BOARD ———▶ KEYBOARD + DISPLAY (3)

2. Make the modifications according to the drawings.



SERVO BOARD A727 1.769.410.20 (BOTTOM VIEW)

