Installation Instructions MO Drive Kit 2.6 GB ISO

20.866.801.00

The Drive Kit includes the following parts:

- 1 MO Drive 2.6 GB (SONY)
- 1 MO Disk 2.3 GB ISO
- 4 Mounting screws M3 × 6
- Installation instructions


1.866.801.00 15.622.260.12

21.53.9354

10.27.4181

Settings


The following settings at the functional switch have to be checked at the rear side of the drive:



Jumper 3 inserted Jumper 7 inserted Jumper 11 inserted (SCSI address 1) (force verify for write) (termination on)

Installation

- 1. Disconnect the unit from mains supply and remove the cover.
- 2. Remove the power cable and the SCSI ribbon cable from the rear side of the currently installed drive.
- 3. Disconnect the old drive by removing the fixing screws (2 at each side). For units with serial number below "1001" which were shipped with the 2.2 GB Pioneer drive, the two drive mounting brackets have to be replaced. The new brackets allow the installation of a wide variety of drives.
- 4. The new ISO drive is mounted from the front of the D424, by sliding it through the frontpanel opening and attach it with the 4 corresponding screws at the brackets.
- **5.** Reconnect both power supply and SCSI ribbon cable to the ISO drive and install the cover again.



Accessories

The 2.6 GB ISO drive is capable of recording and playback the following ISO compatible disks:

	to the second of	
1.2 GB	512 bytes / sector	Order No. 15.622.130.12
1.3 GB	1024 bytes / sector	Order No. 15.622.130.13
2.3 GB	512 bytes / sector	Order No. 15.622.260.12
2.6 GB	1024 bytes / sector	Order No. 15.622.260.13

Prepared and edited by: Studer Professional Audio AG Technical Documentation Althardstrasse 30 CH-8105 Regensdorf – Switzerland

Edition: 30.09.98

Copyright by Studer Professional Audio AG Printed in Switzerland Order no. 10.27.4181 (Ed. 0998)

Subject to change.

Studer is a registered trade mark of Studer Professional Audio AG, Regensdorf

- 1