




C DTS P.C.B. (SIDE : A)




C DTS P.C.B. (SIDE : B)




F HEADPHONES JACK P.C.B.



H SPEAKERS TERMINAL P.C.B.



K AC IN/OUT P.C.B.



ELECTRICAL PARTS LOCATION

Ref. No.	Lo. No.	Ref. No.	Lo. No.	Ref. No.	Lo. No.	Ref. No.	Lo. No.
C DTS P.C.B. (SIDE: A)							
IC1001	2B	R1026	2D	R1054	3D	C1027	1D
IC1002	3E	R1027	3C	R1055	4E	C1029	3C
IC1003	2C	R1028	3B	R1056	4E	C1030	3B
IC1004	2C	R1029	3C	R1057	4E	C1031	3B
IC1005	2E	R1030	2E	R1058	4E	C1032	2E
IC1006	2D	R1031	2E	R1059	4E	C1033	2E
Q1001	2F	R1032	2E	R1060	4E	C1034	2D
L1001	4B	R1033	2D	R1061	4E	C1035	2D
L1002	4C	R1034	2D	R1062	4E	C1036	2D
L1003	2F	R1035	2D	R1063	4E	C1037	2D
L1004	4E	R1036	2D	R1064	4D	C1038	2D
X1001	2E	R1037	3C	R1065	4D	C1039	2E
CN1001	4D	R1038	3C	R1066	3D	C1040	2C
CN1002	4B	R1039	3C	R1067	3D	C1041	2D
R1012	1B	R1040	3C	R1068	4E	C1042	2E
R1013	1B	R1041	3E	R1069	4E	C1043	3E
R1014	1B	R1042	2E	C1003	2B	C1044	3D
R1015	1C	R1043	3E	C1004	4B	C1045	3D
R1016	1C	R1044	3E	C1005	2B	C1046	3D
R1017	1C	R1045	3E	C1006	2D	C1047	3D
R1018	1C	R1046	3D	C1007	3B	C1048	4E
R1019	1C	R1047	3F	C1008	3B	C1049	4D
R1020	1B	R1048	3D	C1009	2E	C1050	3D
R1021	1B	R1049	4E	C1010	3F	C1051	4E
R1022	2B	R1050	4D	C1011	3F	C1052	4E
R1023	2C	R1051	3D	C1024	2B	C1053	4C
R1024	2C	R1052	3D	C1025	2C		
R1025	2B	R1053	3D	C1026	2B		
F HEADPHONES JACK P.C.B.							
CN501	2I	HP601	2G				
H SPEAKERS TERMINAL P.C.B.							
CN601	3K	JK604	2K	C631	2K	C632	2K
K AC IN/OUT P.C.B.							
L701	5H	JK794	5H	W1	6H	W2	6G