


SCHEMATIC DIAGRAM-1

NOTE:
 The number which noted at the connectors on the schematic diagram as "SCHEMATIC DIAGRAM-1" or "SCHEMATIC DIAGRAM-2" indicates the schematic diagram serial number located on the left corner in the schematic diagram.


A TUNER CIRCUIT

: FM OSC SIGNAL LINE
 : FM SIGNAL LINE
 : POSITIVE VOLTAGE LINE
 : AM OSC SIGNAL LINE
 : AM SIGNAL LINE



SCHEMATIC DIAGRAM-2

: POSITIVE VOLTAGE LINE
 : FM SIGNAL LINE
 : AM SIGNAL LINE
 : AM OSC SIGNAL LINE




To **CONNECTOR CIRCUIT (CN102A)** on SCHEMATIC DIAGRAM-4
 To **CONNECTOR CIRCUIT (CN101A)** on SCHEMATIC DIAGRAM-4

SCHEMATIC DIAGRAM-3

B FL CIRCUIT


→ : POSITIVE VOLTAGE LINE - → : NEGATIVE VOLTAGE LINE







SCHEMATIC DIAGRAM-5


MAIN CIRCUIT

: POSITIVE VOLTAGE LINE
 : NEGATIVE VOLTAGE LINE
 : FM SIGNAL LINE
 : AM SIGNAL LINE



SCHEMATIC DIAGRAM-6

 : POSITIVE VOLTAGE LINE
 : NEGATIVE VOLTAGE LINE
 : FM SIGNAL LINE
 : AM SIGNAL LINE



SCHEMATIC DIAGRAM-7

H MAIN CIRCUIT

: POSITIVE VOLTAGE LINE
 : NEGATIVE VOLTAGE LINE
 : FM SIGNAL LINE
 : AM SIGNAL LINE

