

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

DUAL POWER SUPPLY, TEKTRONIX MODEL PS503

(NSN 6695-01-076-8966)

Current as of 5 December 1979

Headquarters, Department of the Army, Washington, DC  
10 January 1980

REPORTING OF ERRORS

You can help improve this publication by calling attention to errors and by recommending improvements and stating your reasons for the recommendations. Your letter or DA Form 2028, Recommended Changes to Publications, should be mailed directly to Commander, US Army Missile Command, ATTN: DRSMI-MFM, Redstone Arsenal, AL 35809. A reply will be furnished directly to you.

	Paragraph	Page								
SECTION I. INTRODUCTION										
Scope-----	1	1								
General -----	2	1								
Explanation of columns -----	3	1								
Special information-----	4	5								
How to locate repair parts -----	5	5								
Abbreviations -----	6	6								
II. REPAIR PARTS LIST -----		9								
<table border="0"> <thead> <tr> <th style="text-align: left;">Functional group</th> <th style="text-align: left;">Group title</th> <th style="text-align: left;">Mode No.</th> <th style="text-align: left;">Part No.</th> </tr> </thead> <tbody> <tr> <td style="padding-left: 40px;">6697</td> <td style="padding-left: 40px;">Dual Power Supply</td> <td style="padding-left: 40px;">PS503</td> <td style="padding-left: 40px;">MIS30526/6</td> </tr> </tbody> </table>	Functional group	Group title	Mode No.	Part No.	6697	Dual Power Supply	PS503	MIS30526/6		
Functional group	Group title	Mode No.	Part No.							
6697	Dual Power Supply	PS503	MIS30526/6							
III. NATIONAL STOCK NUMBER AND PART NUMBER INDEX -----		11								

**Section I. INTRODUCTION**

**1. Scope.** This manual lists spares and repair parts that are required for maintenance of the Dual Power Supply, Tektronix Model PS503. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

**2. General.** This repair parts and special tools list (RPSTL) is divided into the following sections:

**a. Section I.** Introduction.

**b. Section II.** Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in National Stock Number (NSN) sequence.

**c. Section III.** NSN and Part Number Index. A list, in National Item Identification Number (NIIN) sequence, of all NSN's appearing in the listings, followed by a list in alphameric sequence of all part numbers appearing in the listings. NSN's and part numbers are cross-referenced to each illustration figure and item number appearance.

**3. Explanation of Columns**

**a. Illustration.** This column is divided as follows:

**(1) Figure Number.** Indicates the figure number of the illustration on which the item is shown.

**(2) Item Number.** The number used to identify item called out in the illustration.

**b. Source, Maintenance, and Recoverability (SMR) Codes.**

**(1) Source Code.** Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	Definition
PA -	Item procured and stocked for anticipated or known usage.
PB -	Item procured and stocked for insurance purpose because essentiality dictates that a minimum quantity be available in the supply system.
PC -	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD -	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE -	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF -	Support equipment which will not be stocked but which will be centrally procured on demand.

- PG - Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which, because of probable discontinuance or shutdown of production facilities, would prove uneconomical to reproduce at a later time.
- KD - An item of a depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
- KF - An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or intermediate levels of maintenance.
- KB - Item included in both a depot overhaul/repair kit and a maintenance kit.
- MO - Item to be manufactured or fabricated at organizational level.
- MF - Item to be manufactured or fabricated at the direct support maintenance level.
- MH - Item to be manufactured or fabricated at the general support maintenance level.
- MD - Item to be manufactured or fabricated at the depot maintenance level.
- AO - Item to be assembled at organizational level.
- AF - Item to be assembled at direct support maintenance level.
- AH - Item to be assembled at general support maintenance level.
- AD - Item to be assembled at depot maintenance level.
- XA - Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
- XB - Item is not procured or stocked. If not available through salvage, requisition.
- XC - Installation drawing, diagram, instruction sheet, field service drawing, that is identified by manufacturer's part number.
- XD - A support item that is not stocked. When required, item will be procured through normal supply channels.

**NOTE**

**Cannibalization or salvage may be used as a source of supply for any items coded above except those coded XA and aircraft support items as restricted by AR 700-42.**

**(2) Maintenance Code.** Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code	Application/Explanation
C -	Crew or operator maintenance performed within organizational maintenance.
O -	Support item is removed, replaced, used at the organizational level.
F -	Support item is removed, replaced, used at the direct support level.
H -	Support item is removed, replaced, used at the general support level.
D -	Support items that are removed replaced, used at depot, mobile depot, or specialized repair activity only.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code	Application/Explanation
O -	The lowest maintenance level capable of complete repair of the support item is the organizational level.
F -	The lowest maintenance level capable of complete repair of the support item is the direct support level.
H -	The lowest maintenance level capable of complete repair of the support item is the general support level.

D -	The lowest maintenance level capable of complete repair of the support item is the depot level.
L -	Repair restricted to (enter applicable designated specialized repair activity), Specialized Repair Activity.
Z -	Nonreparable. No repair is authorized.
B -	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

**(3) Recoverability Code.** Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability Codes	Definition
Z -	Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
O -	Reparable item. When uneconomically repairable, condemn and dispose at organizational level.
F -	Reparable item. When uneconomically repairable, condemn and dispose at the direct support level.

- H - Repairable item. When uneconomically repairable, condemn and dispose at the general support level.
- D - Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
- L - Repairable item. Repair, condemnation, and disposal not authorized below depot/specialized repair activity level.
- A - Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material). Refer to appropriate manuals/directives for specific instructions.

**c. National Stock Number (NSN).** Indicates the NSN assigned to the item and which will be used for requisitioning.

**d. Part Number.** Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

#### NOTE

**When a stock numbered item is requisitioned, the item received may have a different part number than the part being replaced.**

**e. Federal Supply Code for Manufacturer (FSCM).** The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc.

**f. Description.** Indicates the Federal item name and, if required, a minimum description to identify the item. The physical security classification of the item is indicated by the parenthetical entry (insert applicable physical security classification abbreviation, e.g., Phy Sec C1 (C) -Confidential, Phy Sec C1 (S) -Secret, Phy Sec C1 (T) -Top Secret). Items that are included in kits and sets are listed below the name of the kit or set with the quantity of each item in the kit or set indicated in the quantity incorporated in unit column. When the part to be used differs between serial numbers of the same model, the effective serial numbers are shown as the last line of the description. In the Special Tools List, the initial basis of issue (BOI) appears as the last line in the entry for each special tool, special Test, Measurement, and Diagnostic Equipment (TMDE), and other special support equipment. When density of equipments supported exceeds density spread indicated in the BOI, the total authorization is increased accordingly.

**g. Unit of Measure (U/M).** Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

**h. Quantity Incorporated in Unit.** Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column in lieu of quantity indicates that no specific quantity is applicable (e.g., shims, spacers, etc).

#### 4. Special Information

**a.** Repair parts for components of standards sets which can be identified as existing in the supply system will be requisitioned through normal supply channels from the appropriate supply commodity manager.

**b.** Repair parts for components of standards sets which cannot be identified as to proper supply source will be requisitioned from USAMICOM, using routing identifier B64 and furnishing as a minimum, the following as exception data.

**(1)** Component stock number of the individual end item to be repaired.

**(2)** Component manufacturer's equipment model number and serial number.

**(3)** The equipment manufacturer's stock number as listed in the appropriate manual for the desired repair part.

**(4)** The repair part reference designation, circuit reference, circuit symbol schematic designation, or reference number as listed in the manufacturer's manual.

**(5)** The technical specification of the repair part as contained in the appropriate manufacturer's manual.

**(6)** The title and date of the manufacturer's manual from which the information in paragraphs a, b(3), (4), and (5) above was taken.

#### NOTE

**Repair parts should not be requisitioned for plug-in boards identified in the plug-in board exchange program, except by the depot designated to perform the repair. Repair of calibration set components, with plug-in board assemblies or subassemblies designated as program exchange replacements with a recoverability code of L, will be accomplished by replacing the plug-in board.**

**c.** The plug-in board exchange program functions are as follows:

**(1)** Requisitioning instructions for initial issue plug-in boards will be provided since new instrument boards are included in the program.

**(2)** As a plug-in board covered by the program fails, a replacement will be requisitioned. Requisitions will be submitted to Commander, US Army Missile Command, B64, Redstone Arsenal, AL 35809.

**(3)** Simultaneously with c(2) above, the defective board being replaced will be shipped by certified mail, return receipt requested, to the following address:

Transportation Officer  
Anniston Army Depot  
M/F Field Service Stock  
Anniston, AL 36201

When requisitioning a replacement board, the turn-in document number of the replaced board shall be cited on the requisition.

#### 5. How to Locate Repair Parts

**a.** When NSN or reference number is unknown:

**(1) First.** Using the table of contents, determine the assembly (functional group) within which the repair part belongs.

**(2) Second.** Using the repair parts listing, find the functional group to which the repair part belongs and locate the item by description.

b. When NSN or reference number is known:

**(1) First.** Using the index of NSN's and reference numbers, find the pertinent NSN or reference number. This index is in ascending NSN cross-referenced to the illustration figure number and item number.

**(2) Second.** Using the repair parts listing, find the figure and item number, and locate the figure and item number in the repair parts list.

**6. Abbreviations.** The abbreviations listed below may appear in this RPSTL:

AC-----	alternating current
ACC-----	accordance
ACCUR-----	accuracy
AL-----	aluminum
AMP-----	ampere
ASSY-----	assembly
ASTM-----	American Standard for Testing Materiel
ATTEN-----	attenuation
AWG-----	American Wire Gage
BAN-----	banana
BLK-----	black
BR-----	brass
C-----	centigrade, calibration, cycles per second
CAL-----	calibrate
CAP-----	capacitance
CD-----	code
CER-----	ceramic
COAX-----	coaxial
COMP-----	composition
COND-----	conductor
CONN-----	connector
CONS-----	consisting
CONT-----	continual
COP-----	copper

COR-----	corrosion
CPS-----	cycles per second
CU-----	cubic
CUR-----	current
CYL-----	cylinder
DB-----	decibel
DBL-----	double
DC-----	direct current
DEG-----	degree
DET-----	detector
DIA-----	diameter
DIM-----	dimension
DIV-----	division
DPDT-----	double pole double throw
DPL-----	deployment
ELEC-----	electrical
EQUIPM-----	equipment
F-----	Fahrenheit
FED-----	Federal
FIN-----	finish
FLG-----	flange
FREQ-----	frequency
FSCM-----	Federal supply code for manufacturers
FT-----	foot
GC-----	gigacycles
GEN-----	generator
GHZ-----	gigahertz
GPM-----	gallons per minute
GRAD-----	graduation
H-----	high
HD-----	head
HYDR-----	hydraulic
HZ-----	hertz
ID-----	inside diameter
IN-----	inch
INCL-----	inclusive
K-----	thousand (prefix)
KC-----	kilocycles
KG-----	kilograms
KHZ-----	kilohertz
KMHZ-----	thousand megahertz
KV-----	kilovolts
LAB-----	laboratory
LB-----	pounds
LG-----	length
LT-----	light

M-----	thousand	RPM-----	revolutions per minute
MA-----	milliampere	S-----	single
MAX-----	maximum	SEC-----	seconds
MC-----	megacycles	SECT-----	section
MFD-----	millifarads	SERR-----	serrated
MFR-----	manufacturer	SHK-----	shank
MG-----	milligrams	SNG-----	single
MHZ-----	megahertz	SPEC-----	specification
MIN-----	minimum, minutes	SPL-----	special
ML-----	milliliters	SQ-----	square
MM-----	millimeters	STD-----	standard
MOD-----	modified	STGT-----	straight
MSEC-----	milliseconds	SWG-----	switch
MTL-----	material	SWR-----	standing wave ratio
MV-----	millivolts	SYS-----	system
MW-----	milliwatts	TEL-----	telescopic
NBS-----	National Bureau Standards	TERM-----	terminal
NEG-----	negative	THD-----	thread
NO-----	number	THERM-----	thermometer
NOM-----	nominal	THK-----	thick
NPT-----	National Pipe Thread	TSTR-----	tester
NSN-----	National stock number	U-----	unit
OA-----	overall	UF-----	microfarads
OD-----	outside diameter	UHF-----	ultra high frequency
OPER-----	operating	V-----	volts
OZ-----	ounce	VAC-----	volts alternating current, vacuum
PCS-----	pieces	VDC-----	volts direct current
PCT-----	percent	VHF-----	very high frequency
PF-----	picofarads	VSWR-----	voltage standing wave ratio
PK-----	peck	W-----	watts, with, width
PLTD-----	plated	WT-----	weight
PN-----	part number		
POS-----	positive		
PP-----	peak-to-peak		
PSI-----	pounds per square inch		
PWR-----	power		
REF-----	reference		
REP-----	repetition		
REQ-----	required		
REQMTS-----	requirements		
RES-----	resistance		
RF-----	radio frequency		
RG-----	range		
RH-----	right hand		
RL-----	reel		
RM-----	rack mounted		
RMS-----	root mean square		
ROT-----	rotating		



SECTION II. REPAIR PARTS LIST

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION  USABLE ON CODE	U/M	QTY INC IN UNIT
						GROUP 6697 POWER SUPPLY, DUAL PS503 80009 MIS30526/6 18876		
1	10	PAFZZ	5910-00-782-7614	283-0081-00	80009	CAPACITOR, FIXED, CER.....	EA	1
1	20	PAFZZ	5910-00-139-0362	290-0522-00	80009	CAPACITOR, FIXED, ELE .....	EA	1
1	30	PAFZZ	5910-00-445-3272	VL1770	56289	CAPACITOR, FIXED, ELE .....	EA	1
1	40	PAFZZ	5910-00-407-1764	290-0320-00	80009	CAPACITOR, FIXED, ELE .....	EA	2
1	50	PAFZZ	5910-00-801-1005	9995456	18876	CAPACITOR, FIXED, CER.....	EA	3
1	60	PAFZZ	5910-00-879-0123	8959154-166	49671	CAPACITOR, FIXED, ELE .....	EA	2
1	70	PDFDD	6695-01-084-3984	670-3291-00	80009	CIRCUIT CARD ASSY.....	EA	1
1	80	PDFDD	6695-01-084-3985	670-3291-01	80009	CIRCUIT CARD ASSY.....	EA	1
1	90	PDFDD	6695-01-084-1887	670-3291-02	80009	CIRCUIT CARD ASSY.....	EA	1
1	100	PAFZZ	5910-00-436-3382	152-0040-00	80009	CAPACITOR .....	EA	4
1	110	PAFZZ	5961-01-039-1194	151-0506-00	80009	DIODE .....	EA	2
1	120	PAFZZ	5920-00-842-0224	159-0016-00	80009	FUSE .....	EA	2
1	130	PAFZZ	6240-00-008-4550	CM7220	71744	LAMP, INCANDESCENT .....	EA	2
1	140	PAFZZ	5962-00-365-5977	156-0277-00	80009	MICROCIRCUIT, LINEAR .....	EA	1
1	150	PAFZZ	5962-01-010-7442	156-0067-00	80009	MICROCIRCUIT, LINEAR .....	EA	6
1	160	PAFZZ	5940-00-902-5610	DF21WTC	58474	POST, BINDING, ELECTRONIC .....	EA	1
1	170	PAFZZ	5940-00-915-1024	129-0064-00	80009	POST, BINDING, ELECTRONIC .....	EA	1
1	180	PAFZZ	5940-00-733-6758	DF21GNC	58474	POST, BINDING, ELECTRONIC .....	EA	1
1	190	PAFZZ	5905-00-961-1683	EB2415	01121	RESISTOR, FIXED, COMP .....	EA	1
1	200	PAFZZ	5905-01-064-9049	MFF18X016G14001F	91637	RESISTOR, FIXED, FILM.....	EA	2
1	210	PAFZZ	5905-00-308-7594	RNC60K1212FS	81349	RESISTOR, FIXED, FILM.....	EA	2
1	220	PAFZZ	5905-01-011-8204	HB7515	01121	RESISTOR, FIXED, COMP .....	EA	2
1	230	PAFZZ	5905-00-110-7620	RCR07G102JS	81349	RESISTOR, FIXED, COMP .....	EA	6
1	240	PAFZZ	5905-00-008-8200	301-0152-00	80009	RESISTOR, FIXED, COMP .....	EA	1
1	250	PAFZZ	5905-00-405-7793	321-0170-00	80009	RESISTOR, FIXED, SOIL.....	EA	1
1	260	PAFZZ	5905-01-031-1408	RNC56K1300FS	81349	RESISTOR, FIXED, FILM.....	EA	1
1	270	PAFZZ	5905-00-441-7816	321-0192-00	80009	RESISTOR, FIXED, FILM.....	EA	1
1	280	PAFZZ	5905-01-007-6279	311-1310-00	80009	RESISTOR, VARIABLE .....	EA	1
1	290	PAFZZ	5905-00-131-9729	RCR07G302JS	81349	RESISTOR, FIXED, COMP .....	EA	1
1	300	PAFZZ	5905-00-426-7785	321-0254-00	80009	RESISTOR, FIXED, FILM.....	EA	2
1	310	PAFZZ	5905-00-105-7767	RCR07G474JS	81349	RESISTOR, FIXED, COMP 315-0474-00 FSCM 80009 .....	EA	2
1	320	PAFZZ	5905-01-017-3200	91AR5K	73138	RESISTOR, VARIABLE .....	EA	2
1	330	PAFZZ	5905-01-036-9405	311-1561-00	80009	RESISTOR, VARIABLE .....	EA	2
1	340	PAFZZ	5905-00-369-6916	RCR32G122JS	81349	RESISTOR, FIXED, COMP .....	EA	2

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION  USABLE ON CODE	U/M	QTY INC IN UNIT
1	350	PAFZZ	5905-00-104-8349	RCR20G511JS	81349	RESISTOR, FIXED, COMP .....	EA	2
1	360	PAFZZ	5905-00-120-9154	RCR07G471JS	81349	RESISTOR, FIXED, COMP .....	EA	3
1	370	PAFZZ	5905-00-111-4852	RCR20G2R7JS	81349	RESISTOR, FIXED, COMP 307-0051-00 FSCM 80009 .....	EA	2
1	380	PAFZZ	5905-00-063-6850	308-0245-00	80009	RESISTOR, FIXED, WIREWOUND .....	EA	2
1	390	PAFZZ	5905-01-054-7338	311-1197-00	80009	RESISTOR, VARIABLE .....	EA	2
1	400	PAFZZ	5905-00-135-6046	RCR07G681JS	81349	RESISTOR, FIXED, COMP .....	EA	2
1	410	PAFZZ	5905-00-119-3504	RCR07G273JS	81349	RESISTOR, FIXED, COMP .....	EA	1
1	420	PAFZZ	5905-00-426-7701	321-0216-00	80009	RESISTOR, FIXED, FILM .....	EA	1
1	430	PAFZZ	5905-00-788-0302	321-0213-00	80009	RESISTOR, FIXED, FILM .....	EA	2
1	440	PAFZZ	5905-00-141-0600	RCR20G822JS	81349	RESISTOR, FIXED, COMP 301-0822-00-FSCM 80009 .....	EA	2
1	450	PAFZZ	5905-00-430-0869	301-0302-00	80009	RESISTOR, FIXED, COMP .....	EA	3
1	460	PAFZZ	5905-00-136-8405	RCR07G131JS	81349	RESISTOR, FIXED, COMP .....	EA	2
1	470	PAFZZ	5905-00-106-1356	RCR07G152JS	81349	RESISTOR, FIXED, COMP .....	EA	1
1	480	PAFZZ	5905-01-046-2548	321-0282-00	80009	RESISTOR, FIXED, FILM .....	EA	1
1	490	PAFZZ	5905-01-044-8431	321-0224-00	80009	RESISTOR, FIXED, FILM .....	EA	1
1	500	PAFZZ	5905-01-007-6279	311-1310-00	80009	RESISTOR, VARIABLE .....	EA	1
1	510	PAFZZ	5961-00-936-7719	IR69-6512	81483	SEMICONDUCTOR DEVICE .....	EA	2
1	520	PAFZZ	5961-00-436-2890	152-0280-00	80009	SEMICONDUCTOR DEVICE .....	EA	2
1	530	PAFZZ	5961-00-878-4286	JAN1N971B	81349	SEMICONDUCTOR DEVICE .....	EA	2
1	540	PAFZZ	5961-00-833-3043	JAN1N757A	81349	SEMICONDUCTOR DEVICE .....	EA	1
1	550	PAFZZ	5961-00-237-2353	SZ50646	04713	SEMICONDUCTOR DEVICE .....	EA	1
1	560	PAFZZ	5961-00-436-2888	152-0265-00	80009	SEMICONDUCTOR DEVICE .....	EA	2
1	570	PAFZZ	5961-00-899-8924	1N4152	80131	SEMICONDUCTOR <u>DEVICE</u> 152-0141-02 FSCM 80009 ....	EA	13
1	580	PAFZZ	5961-01-018-2610	150-1001-00	80009	LIGHT EMITTING DIODE .....	EA	3
1	590	PAFZZ	5930-01-034-6694	260-1310-01	80009	SWITCH, PUSH .....	EA	1
1	600	PAFZZ	5961-00-951-8757	JAN2N2222A	81349	TRANSISTOR .....	EA	1
1	610	PAFZZ	5961-00-105-7680	151-0208-00	80009	TRANSISTOR .....	EA	1
1	620	PAFZZ	5961-00-498-2093	151-0136-02	80009	TRANSISTOR .....	EA	1
1	630	PAFZZ	5961-00-365-9935	151-0347-00	80009	TRANSISTOR .....	EA	2
1	640	PAFZZ	5961-00-246-2427	2N4249	80131	TRANSISTOR .....	EA	2
1	650	PAFZZ	5961-00-359-9493	151-0350-00	80009	TRANSISTOR .....	EA	2
1	660	PAFZZ	5961-00-925-3777	JAN2N2907A	81349	TRANSISTOR .....	EA	1
1	670	PAFZZ	5961-01-025-2643	X43C181	03508	TRANSISTOR .....	EA	1

SECTION III. NATIONAL STOCK NUMBER AND PART NUMBER INDEX

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.
6240-00-008-4550	1	130	5940-00-733-6758	1	180
5905-00-008-8200	1	240	5910-00-782-7614	1	10
5905-00-063-6850	1	380	5905-00-788-0302	1	430
5905-00-104-8349	1	350	5910-00-801-1005	1	50
5961-00-105-7680	1	610	5961-00-833-3043	1	540
5905-00-105-7767	1	310	5920-00-842-0224	1	120
5905-00-106-1356	1	470	5961-00-878-4286	1	530
5905-00-110-7620	1	230	5910-00-879-0123	1	60
5905-00-111-4852	1	370	5961-00-899-8924	1	570
5905-00-119-3504	1	410	5940-00-902-5610	1	160
5905-00-120-9154	1	360	5940-00-915-1024	1	170
5905-00-131-9729	1	290	5961-00-925-3777	1	660
5905-00-135-6046	1	400	5961-00-936-7719	1	510
5905-00-136-8405	1	460	5961-00-951-8757	1	600
5910-00-139-0362	1	20	5905-00-961-1683	1	190
5905-00-141-0600	1	440	5905-01-007-6279	1	280
5961-00-237-2353	1	550	5905-01-007-6279	1	500
5961-00-246-2427	1	640	5962-01-010-7442	1	150
5905-00-308-7594	1	210	5905-01-011-8204	1	220
5961-00-359-9493	1	650	5905-01-017-3200	1	320
5962-00-365-5977	1	140	5961-01-018-2610	2	580
5961-00-365-9935	1	630	5961-01-025-2643	1	670
5905-00-369-6916	1	340	5905-01-031-1408	1	260
5905-00-405-7793	1	250	5930-01-034-6694	1	590
5910-00-407-1764	1	40	5905-01-036-9405	1	330
5905-00-426-7701	1	420	5961-01-039-1194	1	110
5905-00-426-7785	1	300	5905-01-044-8431	1	490
5905-00-430-0869	1	450	5905-01-046-2548	1	480
5961-00-436-2888	1	560	5905-01-054-7338	1	390
5961-00-436-2890	1	520	5905-01-064-9049	1	200
5910-00-436-3382	1	100	6695-01-084-1887	1	90
5905-00-441-7816	1	270	6695-01-084-3984	1	70
5910-00-445-3272	1	30	6695-01-084-3985	1	80
5961-00-498-2093	1	620			

PART NUMBER	FSCM	FIG. NO.	ITEM NO.	PART NUMBER	FSCM	FIG. NO.	ITEM NO.
CM7220	71744	1	130	151-0350-00	80009	1	650
DF21GNC	58474	1	180	151-0506-00	80009	1	110
DF21WTC	58474	1	160	152-0040-00	80009	1	100
EB2415	01121	1	190	152-0265-00	80009	1	560
HB7515	01121	1	220	152-0280-00	80009	1	520
IR69-6512	81483	1	510	156-0067-00	80009	1	150
JAN1N757A	81349	1	540	156-0277-00	80009	1	140
JAN1N971B	81349	1	530	159-0016-00	80009	1	120
JAN2N2222A	81349	1	600	2N4249	80131	1	640
JAN2N2907A	81349	1	660	260-1310-01	80009	1	590
MFF18X016G14001F	91637	1	200	283-0081-00	80009	1	10
RCR07G102JS	81349	1	230	290-0320-00	80009	1	40
RCR07G131JS	81349	1	460	290-0522-00	80009	1	20
RCR07G152JS	81349	1	470	301-0152-00	80009	1	240
RCR07G273JS	81349	1	410	301-0302-00	80009	1	450
RCR07G302JS	81349	1	290	308-0245-00	80009	1	380
RCR07G471JS	81349	1	360	311-1197-00	80009	1	390
RCR07G474JS	81349	1	310	311-1310-00	80009	1	280
RCR07G681JS	81349	1	400	311-1310-00	80009	1	500
RCR20G2R7JS	81349	1	370	311-1561-00	80009	1	330
RCR20G511JS	81349	1	350	321-0170-00	80009	1	250
RCR20G822JS	81349	1	440	321-0192-00	80009	1	270
RCR32G122JS	81349	1	340	321-0213-00	80009	1	430
RNC56K1300FS	81349	1	260	321-0216-00	80009	1	420
RNC60K1212FS	81349	1	210	321-0224-00	80009	1	490
SZ50646	04713	1	550	321-0254-00	80009	1	300
VL1770	56289	1	30	321-0282-00	80009	1	480
X43C181	03508	1	670	670-3291-00	80009	1	70
1N4152	80131	1	570	670-3291-01	80009	1	80
129-0064-00	80009	1	170	670-3291-02	80009	1	90
150-1001-00	80009	1	580	8959154-166	49671	1	60
151-0136-02	80009	1	620	91AR5K	73138	1	320
151-0208-00	80009	1	610	9995456	18876	1	50
151-0347-00	80009	1	630				

By Order of the Secretary of the Army:

*Official:*

**E. C. MEYER**  
*General, United States Army*  
*Chief of Staff*

**J. C. PENNINGTON**  
*Major General, United States Army*  
*The Adjutant General*

**Distribution:**

To be distributed in accordance with DA Form 12-34A, requirements for Calibration Procedures Publications.

