

F321		= 160-4208-07																														
A		B		C		D		E		F		G		H		I		J		K										L		
1		ShowAll				Show Folder				Find Instrument				Save EPROM				Burn EPROM														
3		* = not latest version				+ = direct replacement of previous								- = mod required, see microfiche																		
5		INSTRUMENT	POS	VER	DEVICE	U #	P/N	C'SUM	SOCKET	FILE	FOLDER	COMMENTS																				
539		DSA601A	A18	2.23+	27C010	U800	160-4918-07	8C69	1	B1	11																					
540		DSA601A	A18	2.23+	27C010	U810	160-4919-07	E193	2	B1	11																					
541		DSA601A	A18	2.23+	27C010	U820	160-4920-07	5DF6	3	B1	11																					
542		DSA601A	A18	2.23+	27C010	U830	160-4921-07	B338	4	B1	11																					
543		DSA601A	A18	2.23+	27C010	U900	160-4922-07	F966	5	B1	11																					
544		DSA601A	A18	2.23+	27C010	U910	160-4923-07	BDC0	6	B1	11																					
545		DSA601A	A18	2.23+	27C010	U920	160-4924-07	DE39	7	B1	11																					
546		DSA601A	A18	2.23+	27C010	U930	160-4925-07	DCCD	8	B1	11																					
547		DSA601A	A16	2.2+	27C512	U440	160-4782-06	9873	1	B2	11																					
548		DSA601A	A16	2.2+	27C512	U540	160-4783-06	E34E	2	B2	11																					
549		DSA601A	A17	2.23+	27C512	U240	160-5469-07	54B6	3	B2	11																					
550		DSA601A	A17	2.23+	27C512	U250	160-5470-07	F671	4	B2	11																					
551		DSA601A	A19	2.23+	27C512	U410	160-4784-08	012E	1	B3	11																					
552		DSA601A	A19	2.23+	27C512	U510	160-4785-08	E483	2	B3	11																					
553		DSA601A	A19	2.23+	27C512	U420	160-4786-08	0F74	3	B3	11																					
554		DSA601A	A19	2.23+	27C512	U520	160-4787-08	8843	4	B3	11																					
555		DSA601A	A19	2.23+	27C256	U460	160-5955-08	A6B8	1	B4	11																					
556		DSA601A	A19	2.23+	27C256	U560	160-5956-08	9B72	2	B4	11																					
557																																