

Abbreviations - Abreviations - Abkürzungen - Abbreviazioni - Abreviaciones

A H/SW	Audio Head Switching	HA	Head AMP
AC	Alternating Current	HLF	Slice Filter
ACC	Automatic Color Control	HPF	High Pass Filter
ACK	Automatic Color Killer	ID	Identifier
ADJ	Adjustment	KIL	Killer
AE	Audio Erase	LECHA	Character Level
AFC	Automatic Frequency Control	LM	Loading Motor
AFC	Automatic Frequency Control	LP	Long Play
AFT	Automatic Fine Tunning	LPF	Low Pass Filter
AGC	Automatic Gain Control	M/T	Motor
ALC	Automatic Level Control	MESECAM	Middle East Secam
AMP	Amplifier	MOD	Modulation / Mode
APC	Automatic Phase Control	NC	Noise Canceller
AV	Audio Video	OSD	On Screen Display
BG	Burst Gate	PB	Playback
BGP	Burst Gate Pulse	PCB	Printed Circuit Board
BID	Burst Identification	PDC	Program Delivery Control
BPF	Band Pass Filter	PG	Pulse Generator
CAP	Capstan	PIF	Picture IF
CBC	Cable Box Control	PLL	Phase Locked Loop
CCD	Charge Coupled Device	PWM	Pulse width Modulation
CFG	Capstan Frequency Generator	PWR	Power
CLK	Clock	QV SYNC	Quasi-Vertical Sync
COMP	Comparator	REC	Record
CSYNC	Composite Sync	REW	Rewind
CTL	Control	SCL	Serial Clock
DEEMPHA	Deemphasis	SCM	Secam
DEM	Demodulation	SDA	Serial Data
DET	Detect	SEP	Separation
DOC	Drop Out Compensation	SMPS	Switch Mode Power Supply
DRUM FF	Drum Flip Flop	SP	Standard Play
EDS	Extended Data Service	SW	Switching
EMPH	Emphasis	V H/SW	Video Head Switching
ENVE	Envelope	VCA	Voltage Controlled Amplifier
EQ	Equalizer	VCO	Voltage Controlled Oscillator
FBC	Feedback Clamp	VCR	Video Cassette Recorder
FE	Full Erase	VPS	Video Program System
FF	Fast Forward	WD CLIP	White Dark Clip
FG	Frequency Generator	Y/C	Luminance/Chrominance
FNT	Front		
FWD	Forward		

**INFORMATION - INFORMATIONS - HINWEISE -
INFORMAZIONI - INFORMACIONES**

- GB** The table below shows how the Commercial Reference corresponds to X1000 series Chassis Reference number, it also gives additional information that can be used to identify the major components according to chassis type.
- F** Le tableau ci-dessous donne la correspondance entre les références commerciales et les types de chassis de la série X1000, de plus il apporte un complément d'informations permettant d'identifier les composants montés suivant les chassis
- D** Die untenstehende Tabelle zeigt die Zuordnung der Gerätebezeichnungen und der Chassisvarianten der Reihe X1000 an.
- I** La tabella sottostante indica la corrispondenza tra i riferimenti commerciali e i tipi di telaio della serie X1000. Inoltre consente di identificare i principali componenti in base al tipo di telaio.
- E** El cuadro siguiente presenta la correspondencia entre las referencias comerciales y los tipos de chasis de la serie X1000, además ofrece una información complementaria que permite identificar los componentes montados según el tipo chasis.

Com. Ref.	Chassis	Mechadeck	Tuner	ECO
VT2210G	X1000	DRP-8200HVP	SSTMI-GKIQ1 LGTMI-GKIQ1 ALTMi-GKIQ1	YES
VT2220G	X1000	DRP-8200HVP		YES
VT4220G	X1000	DRP-8400HVP		YES
VTH6210G	X1000	DRP-8600HVP		YES
VTH6220G	X1000	DRP-8600HVP		YES
VTH6210U	X1000	DRP-8600HVP		YES
VTH6220U	X1000	DRP-8600HVP		YES
FV606HV	X1000	DRP-8600HVP		YES
VTH6250G	X1000	DRP-8600HVP		YES
VT2220F	X1000	DRP-8200HVP		SSTBI-SLKQ1 SSTBI-SLKQ2
VK2800PS	X1000	DRP-8200HVP	YES	
VT4220F	X1000	DRS-8400HVP	YES	
VTH6250F	X1000	DRS-8600HVP	YES	
VTH6210F	X1000	DRS-8600HVP	SSTBI-SLQ1 LGTBI-SLQ1	YES
VTH6220F	X1000	DRS-8600HVP		YES
VK8810PS	X1000	DRS-8600HVP		YES



EACEM-IRIS REPAIR CODING SYSTEM

SYMPTOM CODE TABLE



CONDITION CODE	MAIN SYMPTOM CODE	EXTENDED SYMPTOM CODE (*1)
1	1	NO ACTION
2	2	LEVEL
3	3	QUALITY
4	4	NOISE
5	5	UNSTABLE
6	6	RECORDING & PHYSICAL PROBLEMS
7	7	SPECIAL FUNCTIONS
8	8	OTHER CONDITIONS
1	GENERAL	110 POWER PROBLEM OR NOT OPERATING 111 NO POWER 112 NO POWER WHEN USING AC-ADAPTER 113 NO POWER WHEN USING DRY BATTERIES 114 NO POWER WHEN USING RECHARGEABLE BATTERIES 115 NO POWER FROM SOLAR CELL 116 NO POWER WHEN USING A CAR BATTERY 117 SHORT OPERATION TIME/SHORT BATTERY LIFE 118 POWER-OFF FUNCTION NOT WORKING 119 NO SWITCH-ON FROM STANDBY 11A POWERS UP, BUT NO OPERATION 11B CYCLIC POWER OFF 11C BLOWING EXTERNAL (MAINS) FUSE 11D SET SWITCHES OFF BY ITSELF 11E BACKUP BATTERY PROBLEM 11F NOT OPERATING 11G NO AUTOMATIC SWITCH ON/OFF 11H PROTECTION SWITCH/FUSE IN SET TRIGGERS 11J RECHARGEABLE BATTERY NOT RECOGNIZED 11X OTHER 'POWER' PROBLEM
1	COMMUNICATION	210 NO RECEPTION OR CONNECTION 211 NO AM RECEPTION 212 NO FM RECEPTION 213 NO SW RECEPTION 214 NO UHF RECEPTION 215 NO UHF RECEPTION 216 NO BS RECEPTION 217 NO CS RECEPTION 218 NO HDTV RECEPTION 219 NO GPS/OPS RECEPTION 21A NO RECEPTION OF DIGITAL BROADCASTING 21B NO IR RECEPTION 21C NO DIAL TONE 21D NO MODEM/FAX CONNECTION 21E MODEM NOT ANSWERING/NO CARRIER 21F NO NETWORK CONNECTION/NETWORK INITIALIZATION FAILS 21X OTHER 'NO RECEPTION' PROBLEM
2	PICTURE	310 NO PICTURE 311 NO PICTURE IN E TO E MODE 312 NO PICTURE IN PLAYBACK MODE 313 NO PICTURE IN VIEWFINDER 314 NO PICTURE, ONLY RASTER 315 NO RASTER, BLACK PICTURE 316 ONLY HORIZONTAL LINE 317 ONLY VERTICAL LINE 318 NO PICTURE IN LCD 319 NO 2nd (OR HIGHER) MONITOR DISPLAY 31X OTHER 'NO PICTURE' PROBLEM
3	COLOUR	410 NO COLOUR 411 NO COLOUR IN E TO E MODE 412 NO COLOUR IN PLAYBACK MODE 413 NO COLOUR IN VIEWFINDER 414 NO COLOUR IN PART OF PICTURE 41X OTHER 'NO COLOUR' PROBLEM
4	AUDIO	510 NO AUDIO 511 NO SOUND IN E TO E MODE 512 NO PLAYBACK OF OUTGOING MESSAGE(S) 513 NO PLAYBACK OF INCOMING MESSAGE(S) 514 NO AUDIO PLAYBACK 515 NO SOUND FROM HANDSET 516 NO SOUND FROM SPEAKER 517 NO SOUND FROM EARPHONE/HEADPHONE 518 NO MICROPHONE SOUND 519 NO SOUND FROM DIGITAL OUTPUT 51X OTHER 'NO AUDIO' PROBLEM
5	MECHANISM	610 NO MECHANICAL OPERATION 611 NO ROTATION OF MOTOR/DISC 612 NO FORWARD OPERATION 613 NO OPERATION FROM PCK MODE 614 NO FAST FORWARD OR REWIND FUNCTION 615 NO LOADING 616 NO UNLOADING OR EJECTING 617 NO AUTO SHUT-OFF OPERATION 618 TONEARM DOES NOT MOVE 619 DISC NOT BEING EJECTED 61A MAGAZINE OR MODULE LOADING/UNLOADING 61B CONTROL/SWITCH NOT WORKING 61X OTHER 'NO MECHANICAL OPERATION' PROBLEM
6	DATA PROCESSING	710 NO DATA PROCESSING OPERATION 711 NO INITIAL SCREEN 712 SYSTEM DOES NOT RESET 713 SYSTEM DOES NOT BOOT UP 714 NO OPERATION FROM PLUG-IN MODULE/PERIPHERAL 715 NO KEYBOARD OPERATION 716 NO OPERATION FROM OTHER INPUT/OUTPUT DEVICE 717 NO DATA STORAGE OPERATION 718 NO DATA COMMUNICATION 719 ERROR MESSAGE DISPLAY 71A HDD BOOT FAILURE 71B FDD BOOT FAILURE 71X OTHER 'NO DATA PROCESSING' PROBLEM
7	PRINT/COPY/SCAN	810 NO PRINT/COPY/SCAN OPERATION 811 NOT PRINTING 812 NO COMMUNICATION WITH PRINTER 813 PAPER NOT LOADING 814 NO PAPER FEED 815 NO IMAGE FIXATION 816 NO DOCUMENT FEEDING 817 SCANNER NOT WORKING 81X OTHER 'NO PRINT/COPY/SCAN OPERATION' PROBLEM
1	GENERAL	120 CHARGING PROBLEM 121 NO BATTERY CHARGING 122 INCOMPLETE BATTERY CHARGE 123 CHARGING TIME TOO LONG 12X OTHER 'CHARGING' PROBLEM
2	LEVEL	220 POOR RECEPTION OR CONNECTION 221 POOR AM RECEPTION 222 POOR FM RECEPTION 223 POOR SW RECEPTION 224 POOR UHF RECEPTION 225 POOR UHF RECEPTION 226 POOR BS RECEPTION 227 POOR CS RECEPTION 228 POOR HDTV RECEPTION 229 POOR GPS/OPS RECEPTION 22A POOR RECEPTION OF DIGITAL BROADCASTING 22B POOR IR RECEPTION 22X OTHER 'POOR RECEPTION' PROBLEM
3	QUALITY	230 TRANSMISSION/CONNECTION PROBLEM 231 NO TRANSMISSION/CONNECTION 232 POOR TRANSMISSION/CONNECTION 233 TRANSMISSION LEVEL TOO HIGH 234 NO TRANSMISSION BETWEEN BASE UNIT AND HANDSET 235 POOR TRANSMISSION BETWEEN BASE UNIT AND HANDSET 236 NO IR TRANSMISSION 237 ONE-SIDED CONNECTION 238 MODEM HANGS UP IMMEDIATELY ONCE CONNECTED 239 MODEM DROPS LINE DURING CONNECTION 23X OTHER 'TRANSMISSION/CONNECTION' PROBLEM
4	NOISE	240 NOISY RECEPTION/TRANSMISSION 241 LINE NOISE 242 OSCILLATION 243 INTERSTATION INTERFERENCE 24X OTHER 'NOISY RECEPTION/TRANSMISSION' PROBLEM
5	UNSTABLE	250 UNSTABLE RECEPTION/TRANSMISSION 251 TUNING DRIFT 252 FADING 253 INTERMITTENT LINE/LINE BREAKING OFF 254 NO OR UNSTABLE CONNECTION COMBINED WITH 'WEAK SIGNAL STRENGTH' INDICATION 25X OTHER 'UNSTABLE RECEPTION/TRANSMISSION' PROBLEM
6	RECORDING & PHYSICAL PROBLEMS	260 TUNING PROBLEM 261 MANUAL TUNING PROBLEM 262 AUTOMATIC TUNING PROBLEM 263 INCORRECT TUNING CHANNEL 264 TUNING MEMORY PROBLEM 26X OTHER 'TUNING' PROBLEM
7	SPECIAL FUNCTIONS	270 SPECIAL COMMUNICATION PROBLEM 271 FAULTY DIALLING 272 FAULTY CHANNEL SELECTION 273 FAULTY AUTO-ANSWER OPERATION 274 FAULTY MESSAGE READ-OUT FUNCTION 275 FAULTY AUTODIAL/REDIAL MEMORY 276 FAULTY TELETEXT/PROCESSING 277 NO RINGING TONE 278 LOUD/WEAK RINGING TONE 279 MODEM STUCK OFF HOOK 27A FAX DOES NOT WORK PROPERLY 27B MODEM CAUSES PROBLEM WITH PHONE 27C NO MODEM DIAL TONE 27X OTHER 'SPECIAL COMMUNICATION' PROBLEM
8	OTHER CONDITIONS	280 SPECIAL RECEPTION PROBLEM 281 FAULTY STEREO RECEPTION 282 FAULTY MAIN CHANNEL (A) FUNCTION 283 FAULTY SUB-CHANNEL (B) FUNCTION 284 FAULTY SSB RECEPTION 285 FAULTY RDS/VPS/PDC/XDS OPERATION 286 FAULTY TELETEXT/CLOSE CAPTION/EPG RECEPTION 287 FAULTY SATELLITE/RTTY RECEPTION 288 FAULTY FAX OPERATION 289 MODEM NOT RECOGNIZED BY SYSTEM 28A FAULTY CALL CHARGE DISPLAY 28B FAULTY HANDS-FREE OPERATION 28C SET LOCKED 28X OTHER 'SPECIAL RECEPTION' PROBLEM
5	UNSTABLE	350 UNSTABLE PICTURE 351 SYNC PROBLEM 352 PICTURE PUMPING 353 PICTURE JITTER 354 PICTURE SHAKING (HORIZONTAL OR VERTICAL) 355 FLICKERING PICTURE 356 FLASHING PICTURE 357 CYCLIC PICTURE MUTING 358 HEAD IMPACT ERROR CAUSING UNSTABLE PICTURE 359 VCR SKEW/H-SHIFT ERROR 35A FROZEN PICTURE 35B JUMPING/REPEATING PICTURE 35X OTHER 'UNSTABLE PICTURE' PROBLEM
6	RECORDING & PHYSICAL PROBLEMS	360 POOR PICTURE RECORDING 361 NO PICTURE RECORDING 362 NO ERASURE PROTECTION FOR VIDEO 363 PREVIOUS VIDEO RECORDING NOT BEING ERASED 364 UNWANTED ERASURE OF PICTURE 365 NO CAMERA RECORDING 366 ONLY ONE FIELD PER FRAME BEING RECORDED 367 RECORDS ONLY A FEW PICTURES 36X OTHER 'PICTURE RECORDING' PROBLEM
7	SPECIAL FUNCTIONS	370 SPECIAL PICTURE FUNCTION PROBLEM 371 EDITING PROBLEM 372 FAULTY FADING/WIPER OPERATION 373 FAULTY NEGATIVE/POSITIVE SWITCHING FUNCTION 374 FAULTY SUPERIMPOSE/TELOP OPERATION 375 FAULTY PICTURE IN PICTURE/DIGITAL PICTURE OPERATION 376 FAULTY PICTURE TRANSMISSION 377 RECORDS ONLY A FEW PICTURES 378 FAULTY GENLOCK FUNCTION 379 FAULTY FLASH/STROBE FUNCTION 37A FAULTY DIGITAL PICTURE/ZOOMING FUNCTION 37B FAULTY AUTO-EDIT FUNCTION 37C FAULTY PICTURE STABILIZER FUNCTION 37D FAULTY STILL OR INDEX PICTURE FUNCTION 37E FAULTY SUBTITLING FUNCTION 37F FAULTY VARIABLE SPEED PLAYBACK 37G FAULTY VIEW-MULTI-ANGLE SWITCHING 37H FAULTY ASPECT RATIO SWITCHING 37I THUMBNAIL OR INDEX PICTURE PROBLEM 37K NO BLANKING SCREEN 37X OTHER 'SPECIAL PICTURE FUNCTION' PROBLEM
8	OTHER CONDITIONS	380 PICTURE DISPLAY/PICKUP PROBLEM 381 BURN MARK ON DISPLAY/PICKUP 382 SCRATCH ON DISPLAY/PICKUP 383 DUST/DIRT ON DISPLAY/PICKUP 384 PHOSPHOR/PIXEL MISSING ON DISPLAY/PICKUP 385 BRIGHT POINT(S) IN PHOSPHOR/PIXEL LINES ACROSS/DOWN IMAGE 386 OUT OF SPECS PIXEL DEFAULTS 387 BACKGROUND BURN IN 38X OTHER 'PICTURE DISPLAY/PICKUP' PROBLEM
5	UNSTABLE	450 UNSTABLE COLOUR 451 COLOUR FLASHING 452 HUE CONSTANTLY CHANGING 453 FLICKERING COLOUR 454 COLOUR NOT LOCKED 45X OTHER 'UNSTABLE COLOUR' PROBLEM
6	RECORDING & PHYSICAL PROBLEMS	460 POOR COLOUR RECORDING 461 NO COLOUR RECORDING 462 NOISY COLOUR RECORDING 46X OTHER 'COLOUR RECORDING' PROBLEM
7	SPECIAL FUNCTIONS	470 SPECIAL COLOUR FUNCTION PROBLEM 471 FAULTY AUTOMATIC WHITE BALANCE 472 FAULTY WHITE BALANCE FUNCTION 47X OTHER 'SPECIAL COLOUR FUNCTION' PROBLEM
8	OTHER CONDITIONS	480 SPECIAL COLOUR FUNCTION PROBLEM 481 FAULTY AUTOMATIC WHITE BALANCE 482 FAULTY WHITE BALANCE FUNCTION 48X OTHER 'SPECIAL COLOUR FUNCTION' PROBLEM
5	UNSTABLE	550 UNSTABLE AUDIO 551 JUMPING OR REPEATING AUDIO 552 AUDIO PUMPING OR BREATHING 553 AUDIO DROPOUTS 554 CYCLIC AUDIO MUTING 555 WOW AND FLUTTER 556 HOWLING/ACOUSTIC FEEDBACK 557 ECHO IN SOUND 55X OTHER 'UNSTABLE AUDIO' PROBLEM
6	RECORDING & PHYSICAL PROBLEMS	560 POOR AUDIO RECORDING 561 AUDIO NOT BEING RECORDED 562 NO ERASURE PROTECTION FOR AUDIO 563 PREVIOUS AUDIO RECORDING NOT BEING ERASED 564 UNWANTED ERASURE OF AUDIO 565 MESSAGE NOT BEING RECORDED 566 DISTORTED AUDIO RECORDING 56X OTHER 'AUDIO RECORDING' PROBLEM
7	SPECIAL FUNCTIONS	570 POOR SPECIAL AUDIO FUNCTION 571 FAULTY FADE OPERATION 572 FAULTY ECHO OPERATION 573 FAULTY MIXING OPERATION 574 FAULTY REPEAT MODE OPERATION 575 FAULTY AUDIO PROCESSING 576 FAULTY SYNC RECORDING OPERATION 577 FAULTY DBB/DOL OPERATION 578 FAULTY NOISE REDUCTION OPERATION 579 FAULTY AUDIO DUB FUNCTION 57A FAULTY TITLE PROGRAMMING 57B FAULTY MIC CONTROL 57C FAULTY FITCH CONTROL 57X OTHER 'SPECIAL AUDIO FUNCTION' PROBLEM
8	OTHER CONDITIONS	580 STEREO/MULTI MODE OPERATION PROBLEM 581 NO STEREO OPERATION 582 POOR CHANNEL SEPARATION 583 DIFFERENCE IN PHASE BETWEEN CHANNELS 584 PROBLEM WITH SURROUND SOUND MODE 585 PROBLEM WITH PCM AUDIO MODE 58X OTHER 'STEREO/MULTI MODE' PROBLEM
6	RECORDING & PHYSICAL PROBLEMS	660 DAMAGE TO MEDIA 661 TAPE GETS SCRATCHED 662 DISC GETS SCRATCHED 663 TAPE GETS CHEWED/WRINKLED 664 TAPE JAMMED OR BROKEN 665 TAPE GETS CURLED 666 SLACK TAPE 667 TAPE STICKING 66X OTHER 'SOFTWARE DAMAGE' PROBLEM
7	SPECIAL FUNCTIONS	670 MECHANICAL OPERATION PROBLEM 671 FAULTY START/STOP OPERATION 672 FAULTY PAUSE OPERATION 673 FAULTY AUTOMATIC PROGRAM SEARCH 674 FAULTY CUE/REVIEW MODE 675 FAULTY SLOW MOTION OPERATION 676 FAULTY HIGH-SPEED SCANNING MODE 677 FAULTY SPEED COPY FUNCTION 678 FAULTY REPEAT OPERATION 679 FAULTY RECORD REVIEW MODE 67A FAULTY AMS OPERATION 67B AUTO-REVERSE MALFUNCTION 67C FAULTY END DETECTION 67D FAULTY DISC DISC (A-B SELECT) SWITCHING 67X OTHER 'MECHANICAL OPERATION' PROBLEM
8	OTHER CONDITIONS	680 LENS PROBLEM 681 FOCUS PROBLEM 682 ZOOM PROBLEM 683 IRIS PROBLEM 684 MACRO PROBLEM 68X OTHER 'LENS' PROBLEM
6	RECORDING & PHYSICAL PROBLEMS	760 DATA STORAGE PROBLEM 761 FORMATTING PROBLEM 762 DATA ON STORAGE MEDIUM BEING LOST 763 FRAME MEMORY PROBLEM 764 READ/WRITE ERRORS 765 HARD-OR OPTICAL DRIVE PROBLEM 766 FLOPPY DRIVE PROBLEM 767 CD/DVD-ROM DRIVE PROBLEM 768 TAPE PROBLEM 769 DRIVE WILL NOT MOUNT/CANNOT ACCESS DRIVE 76A DISCS EXCHANGE PROBLEM 76B READ/WRITE OPERATION VERY SLOW 76X OTHER 'DATA READ/WRITE' PROBLEM
7	SPECIAL FUNCTIONS	770 SPECIAL DATA PROCESSING FUNCTION PROBLEM 771 FAULTY SELF-DIAGNOSTIC MODE 772 FAULTY WORD PROCESSING FUNCTION 773 FAULTY GRAPHIC EDIT FUNCTION 774 PROGRAM CANNOT BE INSTALLED 775 PRE-LOADED PROGRAM CANNOT BE STARTED UP 776 NOT PRE-LOADED PROGRAM CANNOT BE STARTED UP 777 VIRUS ALARM 77X OTHER 'SPECIAL DATA FUNCTION' PROBLEM
8	OTHER CONDITIONS	780 INTERFACE PROBLEM 781 USB INTERFACE PROBLEM 782 PARALLEL INTERFACE PROBLEM 783 SCSI INTERFACE PROBLEM 784 SERIAL INTERFACE PROBLEM 785 INCOMPATIBLE WITH OTHER SYSTEMS 786 AUDIO/VIDEO INTERFACE PROBLEM 787 I/LINK/FIREWIRE/IEEE1394 INTERFACE PROBLEM 78X OTHER 'INTERFACE' PROBLEM
6	RECORDING & PHYSICAL PROBLEMS	860 RIBBON/PAPER PROBLEMS 861 RIBBON BROKEN 862 RIBBON STUCK/STICKING 863 RIBBON DERAILED 864 PAPER STUCK/STICKING TO MECHANISM 865 PAPER JAM 866 DOCUMENT JAM 867 ERONEOUS 'NO INK/TONER' MESSAGE 86X OTHER 'RIBBON/PAPER' PROBLEM
7	SPECIAL FUNCTIONS	870 FAULTY FONT/CHARACTER FUNCTIONS 871 INCORRECT CHARACTERS OR IMAGE 872 INCORRECT CHARACTER SIZE 873 FONT LOADING PROBLEM 874 OTHER 'FAULTY FONT/CHARACTER FUNCTION' PROBLEM
8	OTHER CONDITIONS	880 FAULTY FONT/CHARACTER FUNCTIONS 881 INCORRECT CHARACTERS OR IMAGE 882 INCORRECT CHARACTER SIZE 883 FONT LOADING PROBLEM 88X OTHER 'FAULTY FONT/CHARACTER FUNCTION' PROBLEM

(*) CAUTION
THE 'X' EXTENDED SYMPTOM CODES ('-**X') SHOULD ONLY BE USED TO INDICATE THAT A SUITABLE SYMPTOM DESCRIPTION IS NOT AVAILABLE IN THE CONCERNED SYMPTOM GROUP

