

DK Analogue Handset

To answer a call	Lift receiver
To make a call	Lift receiver and dial 9 and telephone no.
To place a call on hold	Press the R key
To retrieve a held call	Press the R key
To transfer a call	Press the R key, dial extension number, announce call and replace receiver
To retrieve a call	Press the R key
To set a call back on a busy extension	Dial extension number, get busy tone and press 4
To redial last number	Dial ## (This will redial last number dialled internal or external) Or press Redial key
To answer another extension that is ringing in your group	Dial #5#34
To answer another extension that is ringing outside of your group	Lift receiver, and dial #5 and extension which is ringing
To programme personal speed dials	Lift receiver, dial # 66 # * enter speed dial code 10 – 49, enter 9 + Tel no. and # key to store
To use speed dial numbers	Lift receiver, Press the * key and location e.g. 600 – 999 or 10 - 49
To divert your calls immediately	Lift receiver, dial #601, enter internal number to receive calls, replace receiver
To divert on busy	Lift receiver, dial #602, enter internal number to receive calls, replace receiver
To divert on no answer	Lift receiver, dial #603, enter internal number to receive calls, press * key, enter number of secs to ring 08 – 60, press # key and replace receiver
To divert on busy/no answer	Lift receiver, dial #604, enter internal number to receive calls, press * key, enter numbers of secs to ring 08 – 60, press # key and replace receiver
To cancel your divert	Lift receiver, dial #601, replace receiver