

PACKAGE CONTENTS INCLUDE

- evōLO PCN 300 PCMCIA Card
- Easy Start Guide
- CD-ROM with Owner's Manual, Easy Start Guide, and Device Drivers

2 QUICK STEPS TO GET STARTED

1 INSTALL PCMCIA CARD

- With your laptop computer turned Off, insert the **evōLO** 10/100 32-bit PCMCIA network card into an available PCMCIA slot on your laptop computer.

NOTE: Make sure you firmly place the PCMCIA card into the PCMCIA slot with the Uniden logo facing up.

2 INSTALL DRIVERS

- Turn On your laptop computer.
- Insert the **evōLO** CD-ROM into your CD-ROM drive.
- Follow the instructions displayed on your laptop computer screen to install the drivers from the CD-ROM.