

Uniden[®]

evōLO[™] SERIES

PACKAGE CONTENTS INCLUDE

- **evōLO** PCW 200 PCI Adapter
- Easy Start Guide
- CD-ROM with Owner's Manual, Device Drivers, and Wireless Utilities

2 QUICK STEPS TO GET STARTED

EASY START GUIDE

1 INSTALL PCI ADAPTER

- With your desktop computer turned Off, insert the **evōLO** 802.11b Wireless PCI Adapter into an available PCI Adapter slot on your desktop computer.

NOTE: Make sure you firmly place the PCI Adapter into the PCI slot of the desktop computer.

2 INSTALL DRIVERS

- Turn On your desktop computer.
- Insert the **evōLO** CD-ROM into your CD-ROM drive.
- Follow the instructions displayed on your desktop screen to install the drivers from the CD-ROM.

NOTE: Please see the reverse side to setup Microsoft XP's Wireless Configuration tool.

PCW 200

Uniden®

evōlo™ SERIES

XP USERS WIRELESS CONFIGURATION TOOL

- 1** • Right click the Wireless Network Connection icon on the system tray after installing the driver.

- 2** • Select a network from the list and click "Connect" to continue.
 - If the chosen network requires WEP encryption, you will have to enter the WEP key for your network in the "Network key" field.

NOTE: For more details please see the Owner's Manual.