## **Uniden**®

## **evōlo**<sup>™</sup>series

#### **PACKAGE CONTENTS INCLUDE**

- evōLO WNP1000 Wireless Access Point
- Stand

START

- Easy Start Guide
- Owner's Manual

#### **2 STEPS TO GET STARTED**


#### T HARDWARE INSTALLATION

 Plug in your AC power adapter and your ethernet cable into the WNP1000 Wireless Access Point.



### CONNECT THE AP

• Connect the WNP1000 Wireless Access Point to your switch, router, or cable modem.



NOTE: Configuration is not needed when using other Uniden evōLo products.
Your WNP1000 Wireless Access Point has default settings that will work with other Uniden evōLo products, just out of the box.

If you need to configure your WNP1000 Wireless Access Point, you can access the browser based Configuration Utility at http://192.168.1.10. See the Owner's Manual for more information.

# **Uniden**°

## **EVŌLO**<sup>™</sup>SERIES

#### **LED DISPLAY**

LED	State	Description
Power	On	When the device is powered, this LED is on.
Wireless	On	Indicates one or more wireless clients are connected
	Blink	Indicates that wireless data is being transmitted and/or received
	OFF	No wireless transmission occurring.
Ethernet	On	The LED will light up if the WNP1000 Wireless AP is connected to a hub or computer (speed indicated by color).
	Blink	Indicates that data is being transmitted/received
	Green	Indicates the LAN port is operating at 100Mbps
	Amber	Indicates the LAN port is operating at 10Mbps

©2002 Uniden America Corporation, Fort Worth, TX

All rights reserved. Printed in China

WNP1000ESG