

This application note is to help alleviate confusion about measurement of RMS (Root Mean Square) values of AC voltage.

RMS, or Root Mean Square, is the measurement used for any time varying signal's effective value: It is not an "Average" voltage and its mathematical relationship to peak voltage varies depending on the type of waveform. By definition RMS Value, also called the effective or heating value of AC, is equivalent to a DC voltage that would provide the same amount of heat generation in a resistor as the AC voltage would if applied to that same resistor.

Since an AC signal's voltage rises and falls with time, it takes more AC voltage to produce a given RMS voltage. In other words the grid must produce about 169 volts peak AC which turns out to be 120 volts RMS (.707 x 169). The heating value of the voltage available is equivalent to a 120 volt DC source.

Important: This is an example only. This does not mean DC and AC are interchangeable

The typical multi-meter is not a True RMS reading meter. As a result it will only produce misleading voltage readings when trying to measure anything other than a DC signal or sine wave. Several types of multi-meters exist, and the owner's manual or the manufacturer should tell you which type you have. Each handles AC signals differently, here are the three basic types.

A **rectifier type multi-meter** indicates RMS values for sinewaves only. It does this by measuring average voltage and multiplying by 1.11 to find RMS. Trying to use this type of meter with any waveform other than a sine wave will result in erroneous RMS readings.

Average reading digital volt meters are just that, they measure average voltage for an AC signal. Using the equations below for a sinewave, average voltage (V_{avg}) can be converted to Volts RMS (V_{rms}), and doing this allows the meter to display an RMS reading for a sinewave.

A **True RMS meter** uses a complex RMS converter to read RMS for any type of AC waveform.

When taking readings with a non True RMS reading meter, a 120 volt RMS sinewave will still measure about 120 volts RMS. This is because the meter uses the mathematical relationships shown below to give a proper RMS reading for a sinewave. However if used with a modified sinewave or square wave these meters will only read about 90-105 volts. Don't be misled, there is nothing wrong with the inverter or the meter, and to prove this try the following test:

- ◆ Plug in a normal light bulb and check its brightness. If there is only 90-105 volts RMS available it will look orange as it would during a brown out. If it appears to have normal brightness the voltage is approximately 120 VAC RMS.

You can see that improper measurement can easily lead someone to believe that a modified sinewave or square wave inverter is not putting out its rated power.

A few handy things to keep in mind about RMS values that apply only when dealing with a true sine wave, are as follows:

- Peak Volts AC x .707 = V_{rms}
- $V_{rms} = 1.11 \times V_{avg}$
- $1.414 \times V_{rms} = \text{Peak Volts AC}$
- $V_{avg} = .637 \times \text{Peak Volts AC}$

For a modified sinewave or square wave these equations do not apply, and the easiest way to deal with this is to invest in a True RMS reading meter. (For a square wave V_{avg} , V_{rms} , and V_{peak} are all equal.)

Trademarks DURACELL® is a registered trademark of The Gillette Company, used under license. All rights reserved.
XANTREX is a registered trademark of Xantrex International. Other trademarks, registered trademarks, and product names are the property of their respective owners and are used herein for identification purposes only.

Notice of Copyright RMS Values, Meters, and Measurement © August 2007 Duracell. All rights reserved.

Exclusion for Documentation Unless specifically agreed to in writing, Xantrex Technology Inc. ("Xantrex")

- (a) makes no warranty as to the accuracy, sufficiency or suitability of any technical or other information provided in technical notes.
- (b) assumes no responsibility or liability for losses, damages, costs or expenses, whether special, direct, indirect, consequential or incidental, which might arise out of the use of such information. The use of any such information will be entirely at the user's risk; and
- (c) reminds you that if this manual is in any language other than English, although steps have been taken to maintain the accuracy of the translation, the accuracy cannot be guaranteed. Approved Xantrex content is contained with the English language version which is posted at www.xantrex.com.

Date and Revision August 2007 Rev A **Part Number** 976-0168-10-01

Contact Information Telephone: 1 408 987 6359 Web: www.xantrex.com/support