
Technical Note **Installing the Interface Panel**

PROsine

512-0015-01-01 Rev 1

To install the interface panel:

CAUTION:

Turn display panel switch to “off” and disconnect all sources of power before proceeding.

1. Remove LCD panel from the inverter by removing its four screws and disconnecting the cord from the back.
 2. Plug cord into the back of the Interface Panel and install into the cavity with the four screws. DO NOT PINCH THE CORD.
 3. Using the insert card as a template, cut a 2.5" x 2.5" (6.5 mm x 6.5 mm) hole in wall where the LCD panel is to be mounted, and drill the four corner holes. Connect the 30' (10 m) cord from the Interface Panel's “REMOTE OUTPUT” jack, through the mounting hole, to back of the LCD panel.
 4. Secure LCD panel to wall. Holes can accept up to M3 or #4 screws.
 5. Turn inverter on by switching both panels to the “I” position. Either switch in the “off” position will disable inverter.
-

Note:

Bypass mode for transfer relay models: While inverter is in the “off” position, any incoming AC power will be switched to the output load.

Note:

Interface panel may be used to control the inverter without a connected LCD panel. LED is constantly on during normal operation, slow flash or power-save operation (one flash every two seconds), and fast flash for a fault condition (two flashes every second).

PROsine is a trademark of Xantrex International. Xantrex is a registered trademark of Xantrex International.
© 2001 Xantrex International. All rights reserved.

Technical Note: *PROsine – How to Install the Interface Panel* © December 1998 Xantrex International

UNLESS SPECIFICALLY AGREED TO IN WRITING, XANTREX TECHNOLOGY INC. (“XANTREX”):

(a) MAKES NO WARRANTY AS TO THE ACCURACY, SUFFICIENCY OR SUITABILITY OF ANY TECHNICAL OR OTHER INFORMATION PROVIDED IN ITS MANUALS OR OTHER DOCUMENTATION.

(b) ASSUMES NO RESPONSIBILITY OR LIABILITY FOR LOSS OR DAMAGE, WHETHER DIRECT, INDIRECT, CONSEQUENTIAL OR INCIDENTAL, WHICH MIGHT ARISE OUT OF THE USE OF SUCH INFORMATION. THE USE OF ANY SUCH INFORMATION WILL BE ENTIRELY AT THE USER’S RISK.

Part number: 512-0015-01-01 Rev 1

Contact information:

Phone: 1-800-670-0707 (toll-free in North America)

Phone: 1-604-422-2777 (direct)

Fax: 1-604-420-2145 (direct)

Email: CustomerService@xantrex.com

Web: www.xantrex.com