Freedom Remote Control Panel



Battery Status and Freedom Inverter/Charger Remote Control



Monitors and Controls Inverter/Charger System

The Freedom Remote Control Panel allows you to control your Freedom Combi, Freedom 458 and Freedom Marine Series Inverter/Charger system from any convenient location. With controls that can be accessed directly from the front panel, it is easy to read, operate and install.

Product Features

- Independent invert and charge on/off controls
- Push button control of power sharing, equalizing, battery set-up
- Multi-colored LED displays battery state of charge, fault conditions, AC input, DC voltage and DC amperage
- LED warning indictors for low battery and overload warning
- Splash resistant design
- Incoming AC breaker selection allows programmable power sharing
- Easy to install
- One year warranty

Note: The 24-volt models of Freedom Combi inverter/chargers require a different Freedom Remote.

Specifications	
Voltage bar graph	10.0 – 15.5 VDC
DC amps bar graph	Idle mode = off
	Loaded = $<10 - 300$ DC amps
Operating temperature range	0 – 70°C
Compatible battery types	wet/gel/AGM
Design	Splash resistant
Dimensions (L x W x D)	5.75 x 3.75 x 1.75" (146 X 95 X 25 mm)
Cutout size (W x H)	4.875 x 2.875" (116 X 73 mm)
Weight	3 oz (85 g)
Warranty	One year
Part number	84-2056-01

Note: Specifications subject to change without notice.

Xantrex Technology Inc.

Headquarters 8999 Nelson Way Burnaby, British Columbia Canada V5A 4B5 800 670 0707 Toll Free 604 420 1591 Fax

5916 195th Street NE Arlington, Washington USA 98223 800 446 6180 Toll Free 360 925 5144 Fax