

Supplies and Recycling

This topic includes:

- "Supplies" on page 2-50
- "Recycling" on page 2-50

Supplies

The printer's front panel displays status messages and warnings as the supply nears its replacement time. When the front panel prompts you that a supply is low or needs to be replaced, verify that you have replacements on hand. It is important to order these supplies when the messages first appear to avoid interruptions to your printing.

To order supplies, contact your local reseller or visit the Xerox web site at www.xerox.com/office/4500supplies.

Consumables

The only consumables for this printer are the Xerox print cartridges. To order print cartridges, contact your local reseller or visit the Xerox web site at www.xerox.com/office/4500supplies.

Caution

If you attempt to use a non-Xerox print cartridge, it may not fit properly in the printer. If the cartridge does not fit properly, the printer will not function.

Routine Maintenance Items

Routine maintenance items are printer parts or assemblies that have a limited life requiring periodic replacement. Replacements may be in the form of parts or kits. Routine Maintenance Items are typically customer replaceable.

The only routine maintenance item for the Phaser 4500 Laser Printer is the maintenance kit. Access the "Supplies Info" menu from the printer's front panel to see the remaining life for the maintenance kit.

Access the "Supplies Usage Page" from the printer's front panel, from CentreWare IS, or print the "Usage Profile" from the printer's front panel.

Recycling

For information on Xerox supplies recycling programs, go to www.xerox.com/office/recycle.