

## Turning off all color corrections

If you do not want to use any Tektronix color corrections, you can specify no corrections from a Tektronix driver, or with utility files, or with the printer's rear panel switches. Select no corrections when you are using applications that do their own color adjusting.