

Does your application need a PPD file?

Note *For hints and tips on printing from a specific application, request a document catalog from HAL or EuroHAL, the Tektronix automated fax systems.*

Printer description files are required by some applications; *refer to your application's documentation to determine if you need to use one or more of these files.*

Locating the files

Printer description files are located in the *APPLSPEC* directory either on the Phaser 480X CD-ROM (*UTILS* directory) or on the Windows 3.1 Driver and Printer Utilities diskette.

A few applications and their corresponding printer description files are listed in the table below; click the links for details on each printer description file.

Note *Application version numbers and printer description file version numbers do not necessarily match! Use the table below to determine the correct printer description file to use with your application.*

Printer Description Files for the Phaser 480X

Application and version number	Printer description files
QuarkXPress 3.3 (requires Windows 3.1)	TKP480X1.PDF
Aldus PageMaker 5.0	TKP480X1.PPD (version 4.x)
Aldus FreeHand 4.0	TKP480X1.PPD (version 4.x)
Aldus PageMaker 4.0, 4.2, 4.2A (use both PPD and PDX)	TKP480X1.PPD* (version 3.0) TKP480X1.PDX*
Aldus FreeHand 3.0 or 3.1 (use both PPD and PDX)	TKP480X1.PPD* (version 3.0) TKP480X1.PDX*

* **APD files:** version 3.0 PPD and version 3.0 PDX files are not shipped with the printer. Check the Tektronix Bulletin Board Service (BBS) for these files, or call Tektronix Customer Support.

Note *Also included on the Phaser 480X CD-ROM and on the Windows 3.1 Driver and Printer Utilities diskette, is the version 4.x TK480XJ1.PPD file for use with a Japanese Kanji language version of the printer.*

Aldus, Adobe, and other applications

Aldus PageMaker 4.0, 4.2 and 4.2A

Aldus FreeHand 3.0 and 3.1

The version 3.0 PPD file and the version 3.0 PDX file are not shipped with the printer. Check the Tektronix Bulletin Board Service (BBS) for these files, or call Tektronix Customer Support.

Aldus PageMaker 5.0

Aldus FreeHand 4.0

The version 4.x *PPD* printer description file is provided for support of Windows applications, such as newer Aldus applications.

1. Locate the *TKP480X1.PPD* file in the **\PPD4.X** subdirectory in the *APPLSPEC* directory either on the Phaser 480X CD-ROM (*UTILS* directory) or on the Windows 3.1 Driver and Printer Utilities diskette.
2. To use this file, copy it to the directory on your hard disk where other PPD files are located.

For example, the subdirectory in FreeHand's File Manager containing printer description files should be called *ALDUS\USEENGLISH\PPD4*.

Refer to your application's documentation for details on using printer description files.

QuarkXPress

The *TKP480X1.PDF* file is a PostScript printer description file for use with Quark 3.3 and Windows 3.1.

1. Locate the *TKP480X1.PDF* file in the *APPLSPEC* directory either on the Phaser 480X CD-ROM (*UTILS* directory) or on the Windows 3.1 Driver and Printer Utilities diskette.
2. Copy the file to the *PDF* subdirectory of the Quark 3.3 application.

For example:

```
COPY TKP480X1.PDF C:\XPRESS33\PDF
```