

Printing the front panel menu map

The front panel menu map provides a convenient navigation aid for quickly determining the location of menu items. The menu map can be printed from the front panel.

1. While the Ready message is displayed, press the **Menu** button.
The printer displays the first item in the menu:

Help Pages
<---- --> Menu

2. Press the **Menu** button to enter the Help Pages menu. The following message appears:

Test Print
<---- --> Print

3. Press the left arrow (<---) or right arrow (--->) buttons until the following message appears:

Menu Map
<---- --> Print

4. Press the **Print** button to print the menu map page.