

## Enabling and disabling the startup page

1. While the Ready message is displayed, press the **Menu** button. The printer displays the first item in the setup menu:

```
Help Pages
<----- <-----> Menu
```

2. Using the left arrow (<---) or right arrow (--->) buttons, scroll through the selections until the following message appears:

```
Printer Defaults
<----- <-----> Menu
```

3. Press the **Menu** button to access the printer defaults settings.
4. Using the left arrow (<---) or right arrow (--->) buttons, scroll through the selections until the following message appears:

```
Startup Page
<----- <-----> Menu
```

5. Press the **Menu** button to access the startup page settings.
6. Press the right arrow (--->) button once for the following message:

```
Startup Page:disabled
<----- <-----> OK
```

7. Press the **OK** button to disable printing of the startup page.
8. To return to the top level of the menu, press the **Exit** button until the printer displays the Ready message.