

UNIX (Linux)

This topic includes:

- "Quick Install Steps" on page 3-40
- "Additional Resources" on page 3-41

Your printer supports connection to a variety of UNIX platforms through the parallel and network interface. The workstations currently supported by CentreWare for UNIX/Linux to a network-connected printer are:

- Sun Solaris
- IBM AIX
- Hewlett-Packard HP-UX
- DEC UNIX
- Linux (i386)
- Linux (PPC)
- SGI IRIX

The following procedures enable you to connect your printer using any of the supported versions of UNIX or Linux listed above.

Quick Install Steps

From the Printer

1. Verify that both TCP/IP protocol and the proper connector are enabled.
2. At the printer's front panel, select one of these IP address options:
 - Allow the printer to set up a DHCP address.
 - Enter the IP address manually.
3. Print the "Configuration Page" and keep it for reference. For information about printing Configuration pages, go to [Reference/Features/Front Panel](#) on the *User Documentation CD-ROM*.

From Your Computer

1. Access www.xerox.com/office/drivers.
2. Select your printer, the platform you are running (**UNIX**), and file type (**Drivers**).
3. Click **Go to Downloads**.
4. From the list of files provided, download the **PrinterPackageXPXX** and the file that matches your operating system.
5. Print a test page.
6. Verify the print quality of the printed page.

Note

If print-quality problems exist, or if your job did not print, go to [Reference/Troubleshooting](#) on the *User Documentation CD-ROM*. You can also access PhaserSMART Technical Support through CentreWare IS.

Launch your web browser.

- a. Enter the printer's IP address in the browser's **Address** field (<http://xxx.xxx.xxx.xxx>).
- b. Select **Support**.
- c. Click the **PhaserSMART Diagnostic Tool** link to access PhaserSMART.

Additional Resources

- Information about creating a generic print queue in a specific workstation environment can be found in the Xerox infoSMART Knowledge Base at www.xerox.com/office/infoSMART.
- Access the Xerox web site for the latest CentreWare for UNIX drivers at www.xerox.com/office/drivers.
 - a. Select your printer, the platform you are running (**UNIX**), and the files you would like (**Drivers**).
 - b. Click **Go to Downloads**.
 - c. Select the appropriate CentreWare printer driver for your platform.
 - d. Also download the **PrinterPackage XPXX**. It provides the printer-specific features of CentreWare for UNIX driver.