Supplies and Recycling

This topic includes:

- "Supplies" on page 2-52
- "Supply Life Indicators" on page 2-52
- "Recycling" on page 2-53

Supplies

The printer's front panel displays status messages and warnings as the supply nears its replacement time. When the front panel prompts you that a supply is low or needs to be replaced, verify that you have replacements on hand. It is important to order these supplies when the messages first appear to avoid interruptions to your printing.

To order supplies and accessories, contact your local reseller or visit the Xerox web site at www.xerox.com/officeprinting/6250supplies.

Inside the printer, all handles and points of user interaction for replacing supplies are gold.

The following customer usage patterns may significantly reduce toner cartridge life:

- Higher than 5 percent coverage
- Using paper that is larger than letter-size
- Printing jobs of less than 4 pages
- Using Photo print-quality mode
- Using TekColor Correction

Caution

If you attempt to use a non-Xerox toner cartridge, it may not fit properly in the printer. If the cartridge does not fit properly, the printer will not function.

Supply Life Indicators

The Phaser 6250 Color Laser Printer has supply life indicators for consumables and routine maintenance items.

Consumables

Consumables are:

- High-Capacity Toner Cartridges (Cyan, Magenta, Yellow, and Black)
- Standard-Capacity Toner Cartridges (Cyan, Magenta, Yellow, and Black)

Routine Maintenance Items

Routine maintenance items are printer parts or assemblies that have a limited life requiring periodic replacement. Replacements may be in the form of parts of kits. Routine Maintenance Items are typically customer replaceable.

Routine maintenance items for the Phaser 6250 include:

- Imaging Unit
- Fuser
- Transfer Roller

Access the "Supplies Usage Page" from the printer's front panel, from CentreWare IS, or print the "Usage Profile" from the printer's front panel.

Caution

If you attempt to use a non-Xerox toner cartridge, it may not fit properly in the printer. If the cartridge does not fit properly, the printer will not function.

Recycling

For information on Xerox supplies recycling programs, go to www.xerox.com/officeprinting.