











# PHASER® 7700

## COLOR PRINTER

PRINT CARTRIDGE • CARTOUCHE D'IMPRESSION • CARTUCCIA DI STAMPA • DRUCKKARTUSCHE •  
 CARTUCHO DE IMPRESIÓN • CARTUCHO DE IMPRESSÃO • PRINTCASSETTE • SKRIVARKASSETT •  
 Картридж принтера • SKRIVERPATRON • PRINTERKASSETTE • KIRJOITINKASETTI •  
 TISKOVÁ KAZETA • KASETA DRUKARKI • NYOMTATÓKAZETTA •  
 プリントカートリッジ • 打印墨粉盒 • 列印匣 • 인쇄용 잉크 카트리지



<http://www.xerox.com/officeprinting/recycle>

