






PHASER® 7700

COLOR PRINTER



TONER CARTRIDGE • CARTOUCHE DE TONER • CARTUCCIA DI TONER • TONERKARTUSCHE •
 CARTUCHO DE TÓNER • CARTUCHO DE TONER • TONERCASSETTE • TONERKASSETT •
 КАРТРИДЖ С ТОНЕРОМ • TONERKASSETT • TONERPATRON • VÄRIKASSETTI •
 ZÁSOBNÍK TONERU • KASETA Z TONEREM • FESTÉKKAZETTA •
 トナーカートリッジ • 墨粉盒 • 碳粉匣 • 토너 카트리지



<http://www.xerox.com/officeprinting/recycle>

