






Adding Memory

Ajout de mémoire • Aggiunta di memoria • Aufrüsten des Speichers • Adición de memoria • Adição de memória • Geheugen toevoegen • Lägg till minne • Installere minne • Tilføj hukommelse • Muistin lisääminen • Добавление памяти • Přidávání paměti • Rozszerzenie pamięci • Memóriabővítés • Προσθήκη μνήμης • メモリの追加




See the instructional video at
www.xerox.com/office/7750support



4**5****6**

Print Configuration Page
Imprimir página de configuración
Imprimer la page de configuration
Konfigurationsseite drucken
Stampa pagina di configurazione
Imprimir Página de Configuração
Configuratiepagina afdrukken
Skriv ut konfigurationssidan
構成ページ出力

**7**