







7750B to 7750DN Upgrade Kit

Kit de mise à niveau 7750B à 7750DN • Kit di aggiornamento da 7750B a 7750DN • Upgrade-Kit – 7750B auf 7750DN •
 Kit de actualización de 7750B a 7750DN • Kit atualização de 7750B para 7750DN • Upgrade-kit van 7750B naar 7750DN •
 Uppgraderingsatts för 7750B till 7750DN • Oppgraderingssett fra 7750B til 7750DN • 7750B til 7750DN oppgraderingspakke •
 7750B-7750DN-päivityssarja • Набор для модернизации 7750B - 7750DN • Sada pro aktualizaci soupravy 7750B na 7750DN •
 Zestaw do rozbudowy drukarki 7750B do 7750DN • 7750B - 7750DN frissítőkészlet • Kit Αναβάθμιση 7750B σε 7750DN •
 7750B から 7750DN へのアップグレードキット




See the instructional video at
www.xerox.com/office/7750support




3.4

RAM 2

RAM 1




3.5




4


4.1




4.2




5



6



7



Print Configuration Page
 Imprimir página de configuración
 Imprimer la page de configuration
 Konfigurationsseite drucken
 Stampa pagina di configurazione
 Imprimir Página de Configuração
 Configuratiepagina afdrukken
 Skriv ut konfigurationssidan
 構成ページ出力

8

