


**1**



**2**


Phaser® 8200  
Printer is shutting down

Standard Shutdown


**Shutdown For Moving**

Desconexión para mover  
Arrêt pour déplacer  
Abschalten zum Transport  
Spegner prima di trasportare la stampante  
Desligar para mover a impressora  
Uitzetten voor verplaatsen  
Stäng av för att flytta skrivaren  
移動のためシャットダウン  
关闭以便移动打印机  
標準關機以便搬動印表機  
프린터 이동을 위한 종료


**3**



**4**



**5**




Instructions de remballage  
Istruzioni per l'imballaggio  
Wiederverpackungsanleitung  
Instrucciones para el reembalaje  
Instruções para a reembalagem  
Instructies voor het opnieuw inpakken  
Ompackningsinstruktioner  
Инструкции для повторной упаковки  
Anvisninger vedrørende ompakking  
Nedpakningsinstruktioner  
Uudelleenpakkausohjeet  
Návod k zabalení  
Instrukcje ponownego pakowania  
Újracsomagolásra vonatkozó utasítások  
再収納の説明  
重包装说明  
重新包裝指示  
재포장 지시

**Tektronix**


COLOR PRINTERS BY

**XEROX**


6



7





8




9




36 kg  
79 lbs.




10




11




11.1



11.2



11.3



12

