

Notice of Alterations

YS1000 Series
YS1500, YS1700, YS1310, YS1350, YS1360


YS1000 Series

Please make the alterations described below to the following Operation Guides and User's Manuals.

- (1) YS1500/YS1700 Operation Guide (IM 01B08B01-01E)
- (2) YS1500/YS1700 User's Manual (IM 01B08B01-02E) (Electronic version in the provided CD)
- (3) YS1310 Operation Guide (IM 01B08D01-01E)
- (4) YS1310 User's Manual (IM 01B08D01-02E) (Electronic version in the provided CD)
- (5) YS1350/YS1360 Operation Guide (IM 01B08E01-01E)
- (6) YS1350/YS1360 User's Manual (IM 01B08E01-02E) (Electronic version in the provided CD)

Note

YS1500/YS1700 Operation Guide
Expandable I/O Cable (YS011) (p. 46)



Please ignore the pin number of the connector.
Expandable I/O Terminal (YS010) (p. 46)
Weight: 260g

Each Operation Guide

Model and Suffix Codes (p. 5)

Please add the optional code /DF (Direct input with Fahrenheit temperature range function) to the Direct input.

This optional code /DF can be combined only with optional code /A02 or /A03.

User's Manual (CD)

YS1500/YS1700 Chapter 5, Adjusting Direct Inputs (Temperature/Resistance/Frequency) (p. 5-1)

YS1310 Chapter 3, Adjusting Direct Inputs (Temperature/Resistance/Frequency) (p. 3-1)

YS1350/YS1360 Chapter 3, Adjusting Direct Inputs (Temperature/Resistance/Frequency) (p. 3-1)

Please add the following to the B09 setting item.

If optional code /DF is specified, Fahrenheit temperature range can be used for direct input range in addition to Centigrade temperature range.